



SERVICE MANUAL

122

MASTER CASSETTE DECK

Effective: April, 1981 B10041


5704008406


TABLE OF CONTENTS

1 Spec	ifications	3	6-4.	Capstan assembly thrust	44
	ures and controls	Ü	6-5.	Takeup torque	
2.1 641	Front panel features and controls	4	6-6.	Fast forward and rewind torque	
2-2.	Rear panel connections	5	6-7.	Pinch roller pressure	
	uit description	-	6-8.	Tape speed	
	ol section		6-9.	Wow and flutter	
3-1.	System control IC	6		ord/reproduce amplifier checks and	
3-2.	System control IC input/output	_		stments	
-	circuits	9	7-1.	Reproduce output level setting	47
3-3.	Solenoid drive circuit		7-2.	VU meter setting	
3-4.	Reel motor drive circuit		7-3.	Reproduce frequency response	
3-5.		18	7-4.	Bias setting adjustment	
3-6.	Tape-end detection circuit	18	7-5.	Record level	
3-7.	Memory circuit		7-6.	Overall frequency response	48
3-8.		20	7-7.	Overall signal-to-noise ratio	49
3-9.	Overall operation of the deck	24	7-8.	Overall distortion	
3-10.	Muting circuits		7-9.	Erasure	
Ampl	ifier section			Channel separation	50
3-11.	Reproduce circuit	30	7-11.	LED lighting of VU meter (PEAK	
3-12.	Monitor circuit	32		indicator)	
	Record circuits			Dolby Noise Reduction effect	
3-14.	Dolby HX circuit	37		Dolby HX effect	
	s location	41		Headphones output level	
	ntial maintenance			Bias trap adjustment	
	pment/material			BIAS/REC calibration check	
	tro-mechanical checks and adjustment			loded views and parts lists	
	Head base plate positioning	43		poards and parts lists	
6-2.	Microswitch (A) assembly	AND 1988		iconductors lists	
	clearance	43		embling hardware coding lists	
6-3.	Microswitch (B) assembly		12. Bloc	:k-diagram	69
	clearance	43			

NOTES: 1. In the diagram of each PC board, its pattern surface is shown.

- 2. With certain exceptions, the reference numbers in the 100's, 300's and 700's refer to the Lch, and those in the 200's, 400's and 800's to the Rch.
- 3. Parts marked with \triangle are safety critical components. They must always be replaced with components specified by TEAC.
- 4. Service data are found where they are necessary. Improvements may result in service data changes without notice.
- Dolby Noise Reduction System manufactured under license from Dolby Laboratories Licensing Corporation.
- 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.





1. SPECIFICATIONS

MECHANICAL Tape: Philips Type Cassette C-60 and C-90 Track Format: 4-Track, 2-Channel Stereo Tape Speed: 1-7/8 ips and 3-3/4 ips ±0.5 % Deviation ±0.5 % Deviation Speed Accuracy: 1-7/8 ips 3-3/4 ips ±0.085 % peak (DIN/IEC/ANSI weighted) Wow & Flutter: 1-7/8 ips 1) ±0.18 % peak (DIN/IEC/ANSI unweighted) 0.06 % (NAB weighted) 0.11 % (NAB unweighted)
±0.055 % peak (DIN/IEC/ANSI weighted)
±0.13 % peak (DIN/IEC/ANSI unweighted) 3-3/4 ips 2) 0.04 % (NAB weighted) 0.07 % (NAB unweighted) **Fast Wind Time:** 90 secs. for MTT-501 (C-60) Motor: 1 FG Serva Controlled DC Motor 1 DC Reel Motor 3 Heads; Erase, Playback/Record **Head Configuration:** 482 x 147 x 345 mm (19" x 5-13/16" x 13-9/16") Dimensions (WxHxD): Weight: 19-13/16 lbs. (9 kg) net **ELECTRICAL** Line Input 1, 2: Input Impedance: 50k ohms unbalanced Maximum Source Impedance: 10k ohms or less -14 dBV (190 mV) Nominal Input Level: -24 dBV (60 mV) Minimum Input Level: Line Output: Minimum Load Impedance: 25k ohms or more, unbalanced Output Impedance: 3.5k ohms or less -10 dBV (0.3 V) -7.5 dBV (0.42 V) Nominal Output Level: Maximum Output Level: Headphone Output: 100 mW Maximum at 8 ohms Bias Frequency: 100 kHz Equalization: 1-7/8 ips $3180 \mu s. + 70 \mu s.$ 3180 μ s. + 120 μ s. switchable 3180 μ s. + 35 μ s. 3180 μ s. + 50 μ s. switchable 35 Hz - 14 kHz ±3 dB at -20 VU 35 Hz - 6.3 kHz ±3 dB at 0 VU 3-3/4 ips Frequency Response3) 1-7/8 ins (Record/reproduce): $35~Hz-20~kHz\pm3~dB$ at -20~VU $35~Hz-15~kHz\pm3~dB$ at 0~VU3-3/4 ips 1 % at 0 VU, 1 kHz, 160 nWb/m Total Harmonic Distortion (THD)3): 1-7/8 ips 3 % at 9 dB above 0 VU, 1 kHz, 451 nWb/m 3-3/4 ips 3 % at 10 dB above 0 VU, 1 kHz, 506 nWb/m Signal to Noise Ratio³⁾: At a reference of 3 % distortion level 1-7/8 ips 58 dB weighted 55 dB unweighted' 92 dB weighted with DBX

3-3/4 ips 63 dB weighted

58 dB unweighted

92 dB weighted with DBX

Adjacent Channel Separation: Erasure:

Headroom:

Better than 35 dB at 1 kHz Better than 65 dB at 1 kHz + 10 VU reference

Recording Amplifier: Reproduce Amplifier: Power Requirements:

Better than 19 dB above 0 VU Better than 19 dB above 0 VU

100/120/220/240 V AC, 50/60 Hz, 41 watts (General Export Model),

120 V AC, 60 Hz, 41 watts (U.S.A./Canada Model), 220 V AC, 50 Hz, 41 watts (Europe Model), 240 V AC, 50 Hz, 41 watts (U.K./Australia Model)


In these specs. O dBV is referenced to 1 V.

- 1) Specifications were determined using TEAC Test Tape MTT-111.
- Specifications were determined using TEAC Test Tape MXT-111.
- 3) Specifications were determined using TEAC Test Tape MTT-506.

Changes in specifications and features may be made without notice or obligation.

2. FEATURES AND CONTROLS

2-1. FRONT PANEL FEATURES AND CONTROLS



• POWER switch

MEMORY switch

This works in conjunction with the TAPE COUNTER and rewind function to rewind to any required part of the tape. The tape will be rewound to the 000 position on the tape counter (actually to 999, just past the 000 position). The 000 position can be reset at any position on the tape by pressing the reset button. If the ME-MORY switch is in the STOP position, when the rewind (<
) button is pressed, the tape will be rewound until the counter has counted down to 999 (just beyond 000) and the tape will stop automatically. If the MEMORY switch is in the PLAY position, when the counter has counted down to 999, the tape will stop and then be played back automatically.

9 PHONES control

Adjusts the output volume for the headphones.

O PHONES jack

Suitable for 8-ohm stereo headphones.

6 Cassette holder

The face plate of this door can be removed for easy access to the heads for cleaning, etc.

Transport controls

- ► (Play) button
- ← (Rewind) button
- **→** (Fast Forward) button

STOP button

EJECT button

RECORD button

PAUSE button

REC MUTE (Record Muting) button

If the REC MUTE button is pressed while a recording is being made, only an erase signal is applied to the tape.

To release the record muting mode, press either the play (▶) or PAUSE button.

1NPUT LINE 2 jacks

This pair of RCA jacks is provided as a convenience, and duplicates the function of the rear (LINE 1) input jacks for connecting a receiver or other line level source to the 122.

3 INPUT (LEFT, RIGHT) controls

These controls are used to adjust the levels of the left and right input signals to be recorded on the tape. The left and right controls are geared together to allow simultaneous adjustment of both channels. To adjust one channel independently of the other (to alter the channel balance), hold one knob while turning the other.

BIAS/REC CALIBRATION trimmers and button switch

With the button in the PRE-SET (out) position, the bias levels suitable for recording on normal, cobalt (Co), chromium dioxide (CrO_2) and metal tape can be selected using the BIAS switch, while the reference recording level is adjusted to match the average sensitivity for each type of tape. These factory-preset levels are average values for the three types of tape. For precise calibration of the bias and recording levels to exactly match a specific tape, set the button to the ADJUST (in) position and adjust the trimmers using a screwdriver.

O OUTPUT control

This knob is used to adjust the level of the signals delivered from the OUTPUT jacks on the rear panel. Both channels are adjusted together. The readings of the VU meters are not affected by this control.

Function switches

MONITOR switch

This switch selects the signals fed to the headphones (PHONES) jack and the OUTPUT jacks, and is indicated by the VU meters.

SOURCE: Selects the input connected to the LINE 1 (rear) or LINE 2 (front) jacks. The levels displayed by the VU meters depend on the setting of the INPUT controls.

TAPE: Selects the signal from the tape. The levels displayed by the VU meters are the levels of the signals recorded on the tape; they are not affected by the setting of the OUTPUT control.

Note: For tape playback the MONITOR switch must be in the TAPE position.

NR SYSTEM switch

DOLBY SYSTEM/NR: Selects the built-in Dolby Noise Reduction circuit. This position is used to make a Dolbyized recording or to reproduce a Dolby-encoded cassette.

DOLBY SYSTEM/NR + HX: Selects the Dolby Noise Reduction circuit and also the Dolby Headroom Extension (HX) circuit which gives greater headroom in recording. Tapes recorded with the switch in this position can be played back with the switch in the same position or in the DOLBY SYSTEM/NR position.

dbx (EXT)/OUT: Use this position to record or reproduce without noise reduction or when USING THE OPTIONAL RX-8 DBX NOISE REDUCTION UNIT.

INPUT switch

This switch selects the signals fed to the recording circuit for recording.

LINE 1: Selects the signals applied to the rear panel LINE IN jacks.

LINE 2: Selects the signals applied to the front panel LINE 2 jacks.

TEST: Use this position when setting the bias and recording level calibration controls using a separate signal generator.

SPEED switch

HIGH: Selects a tape speed of 3-3/4 ips.

STANDARD: This selects the normal cassette tape speed of 1-7/8 ips.

EQ switch

Selects the equalization characteristics of the 122 to match the type of tape being used.

NORMAL: The equalization is 120 μ s.

Co (CrO₂): The equalization will match cobalt or chromium dioxide tape.

METAL: The equalization will match metal tape. **Note:** The EQ switch should be set to match the tape for both recording and playback.

BIAS switch

Selects the factory-preset bias levels to match the type of tape being used for recording (with the BIAS/REC CALIBRATION button in the PRE-SET position).

NORMAL: The bias will match normal low-bias tape.

Co (CrO_2): The bias will match cobalt or chrome-equivalent tape.

METAL: The bias will match metal tape.

Note: The bias has no effect during playback, by it must be set correctly when recording to get optimum performance from the tape being used.

VU meters

A PEAK LED is provided in each meter; this lights to warn of overload at +8 dB input level which could result in distorted recording.

® TAPE COUNTER

2-2. REAR PANEL CONNECTIONS

OUTPUT (R, L) jacks

LINE 1 (R, L) jacks

DBX UNIT terminals

These eight RCA pin-terminals are used for the connection of the optional RX-8 dbx noise reduction unit. If the RX-8 is not used, the U-link plugs provided must be left in place.

DBX UNIT CONTROL SIGNAL socket

This is a special socket which feeds the control signal to the optional RX-8 dbx noise reduction unit.

REMOTE CONTROL socket

Allows connection of the optional TEAC RC-90 Remote Control unit.

3. CIRCUIT DESCRIPTION

The following conditions are assumed:

* The deck is initially in the stop mode unless otherwise specified.

* Voltages, waveforms, and operating times given in the text are typical ones for reference.

* In the description of amplifiers (sections 3-11 through 3-14), generally, the left channel is described.

* In the illustrations, circuit boards, terminals, and connectors are omitted.

* Part numbers are assigned as follows:

100—199: Muting circuit, bias oscillator circuit, and L-channel record/reproduce circuit mounted on record/reproduce & control PCB

200-299: R-channel record/reproduce circuit on record/reproduce & control PCB

300-399: L-channel monitor, record, and HX circuits and common L- and R-channel circuits mounted on lever switch PCB

400-499: R-channel monitor, record, and HX circuits mounted on lever switch PCB

500-599: Power supply PCB circuits.

600-699: System control circuits and mechanical parts mounted on record/reproduce & control PCB and joint PCB 700-799: L-channel meter circuit and phone

amplifier circuit mounted on

meter amplifier PCB

800-899: R-channel meter circuit and phone

amplifier circuit mounted on

meter amplifier PCB

CONTROL SECTION

3-1. SYSTEM CONTROL IC

3-1-1 Pin assignments




Fig. 3-1 Pin assignments

	Pin No.	Pin name	Fund	tion had a second secon				
	1	PLAY	Reproduce start signal input terminal.	Signal level: L				
Operation inputs	2	STOP	Stop signal input terminal	Signal level: L				
	3	F.FWD	Fast-forward signal input terminal.	Signal level: L				
	5	REW	Rewind signal input terminal.	Signal level: L				
	6	PAUSE	Pause signal input terminal.	Signal level: L				
	7	REC	Record signal input terminal.	Signal level: L				
Control	4	мемо	Memory input terminal (resets rewind mode when at L level)					
inputs	9	AR	Record inhibit signal input terminal (L level: record inhibited, H level: record enabled)					
LD	10	REC	H-level signal output terminal during record/reproduce or record/pause mode					
	11	PAUSE	H-level signal output terminal during pause mode					
Outputs	12	PLAY	H-level signal output terminal during reproduce mode.					
power	13	REW	H-level signal output terminal during rewind mode.					
14 FAST		FAST	H-level signal output terminal during rewind or fast-forward mode.					
	15	F.FWD	H-level signal output terminal during fast-forward mode.					
Power	8	GND	Ground terminal.					
LOMEI	16 +B		. Power supply terminal (standard: +5 V +/-10%, absolute maximum: +7.0 V)					

3-1-2 Block diagram




Fig. 3-2 Block diagram

3-1-3 Input signals and resulting modes

Output signal Input signal	REC	PAUSE	PLAY	REW	FAST	F. FWD	Operating mode
PLAY	L	L	Н	L	L	L	PLAY mode
STOP	L	L	L	L	L	L	STOP mode
F.FWD	L	L	L	L	Н	Н	F.FWD mode
REW	L	L	L	Н	Н	L	REW mode
PAUSE	L	Н	L	L	L	L	PAUSE mode
REC and PLAY	Н	L	Н	L	L	L	REC/PLAY mode
REC and PAUSE	Н	Н	L	L	L	L	REC/PAUSE mode

Notes 1. The mode is set at the decaying edge of the input signal waveform.

2. The output retains the current mode until an input signal indicating a different mode is received.

3. Output REC remains at L as long as input AR is L.

4. Output REW remains at L as long as input MEMO is L.

3-1-4 Mode transition

The table below summarizes transition from one to another due to an input signal.

Current Mode Input signal	STOP	F.FWD	REW	PLAY	PAUSE	REC/PLAY	REC/PAUSE
STOP		STOP	STOP	STOP	STOP	STOP	STOP
F.FWD	F.FWD		F.FWD	F.FWD	F.FWD	F.FWD	F.FWD
REW	REW	REW		REW	REW	REW	REW
PLAY	PLAY	PLAY	PLAY		PLAY		REC/PLAY
PAUSE	PAUSE			PAUSE		REC/PAUSE	
REC and PLAY	REC/PLAY	REC/PLAY	REC/PLAY	REC/PLAY	REC/PLAY		REC/PLAY
REC and PAUSE	REC/PAUSE			REC/PAUSE	REC/PAUSE	REC/PAUSE	

Note. A diagonal line indicates that the current mode remains unchanged.

3-1-5 Operation with more than one input signal

When more than one input signal is received simultaneously, the deck enters the mode indicated below. When input signals applied simultaneously are removed in sequence, the mode indicated by the last signal to be removed is normally enabled. If REC and PLAY or REC

and PAUSE are combined, the record/reproduce or record/pause mode will be enabled regardless of the sequence in which the input signals are removed. If F.FWD (REW) and REC or PAUSE are combined, the fast-forward (rewind) mode will be enabled regardless of the sequence in which the input signals are removed.

Input signal A	Input signal B	Resulting mode
STOP	Any combination of F.FWD, REW, REC, PAUSE, and PLAY	STOP mode
	REW	STOP mode
F.FWD	REC and/or PAUSE	F.FWD mode
	PLAY	STOP mode
REW	REC and/or PAUSE	REW mode
U E AA	PLAY	STOP mode
	PAUSE	REC/PAUSE mode
REC	PLAY	REC/PLAY mode
	PAUSE and PLAY	REC/PAUSE mode
PAUSE	PLAY	REC/PLAY mode

3-1-6 Input/output levels

Input/cutput levels and voltages are given below.

Item	Minimum	Standard	Maximum	Absolute maximum
Maximum supply voltage	<u> </u>		-	7.0 V
Maximum input voltage				5.5 V
Recommended supply voltage	4.5 V	5.0 V	5.5 V	
H-level input voltage	2.0 V		<u> </u>	
L-level, input voltage			0.8 V	A Service Line of specifics
Open-input voltage	3.2 V			
H-level output voltage	2.9 V		Dale in the state of the	
L-level output voltage			0.4 V	

3-2. SYSTEM CONTROL IC INPUT/OUTPUT CIRCUITS

3-2-1 Initial reset circuit

See Fig. 3-3.

The initial reset circuit generates a signal which puts the deck in the stop mode immediately after power is turned on, preventing incorrect operation during the time the DC supply voltage is unstable.

1) When no cassette is loaded

When no cassette is loaded, cassette-in switch S695 is set to N.O., which is the state entered when the stop button is depressed. In this way the deck enters the stop mode when power is turned on.

2) When a cassette is loaded

When a cassette is loaded, cassette-in switch S695 is set to N.C. and isolated from the stop circuit. If the power is turned on at this time, current from system control IC U601 charges

the noise suppressing capacitors (C601 – C607) in the control input circuit of U601. It takes approximately 20 msec to charge C601 – C605 due to their low capacity. When the capacitors are fully charged, the PLAY, PAUSE, F.FWD, REW, and REC input terminals switch to H level. It takes approximately 100 msec for the STOP input terminal (and MEMO input terminal) to rise to H level since C606 has a large capacity. In this way, of the operation input terminals, only STOP takes longer to switch to H level. As a result, a flip-flop is reset in U601 when power is turned on and the deck enters the stop mode.

Unless C606 is fully charged and the STOP input terminal is at H level, U601 does not switch from the stop mode to another mode even if operation signals are input.




Fig. 3-3 System control IC input/output circuits

3-2-2 Output control circuit

When power is turned on, the initial reset circuit puts U601 in the stop mode. This circuit does not operate when power is turned off.

When power is cut off and +5.3 V is decaying, U601 may generate a wrong signal momentarily due to deviation from the logic threshold level. The circuit comprising Q606, D605, R629, and R630 prevents the mis-operation of the deck if U601 generates an incorrect signal.

When +5.3 V supply voltage falls to approximately 5 V after power is turned off, zener diode D605 turns off and, therefore, Q606 turns off together because its base current is cut off. As Q606 is off, the emitters of transistors Q601 — Q605 are disconnected from the 0 V (GND) line. As a result, Q601 — Q605 will not turn on even if U601 generates an incorrect signal while +5.3 V supply voltage is falling. This protects the deck from erroneous operation.

Further, if power is turned off when the deck is operating in any mode, the deck enters the stop mode as soon as 0.606 turns off, preventing the tape from becomming slack.

On the other hand, when power is turned on, D605 and D606 do not go on until the $+5.3\,\mathrm{V}$ line rises to approximately 5 V. Q601 - Q605 do not operate before Q606 is turned on. This means the deck does not start to operate before the DC supply voltage is sufficiently high.

3-3. SOLENOID DRIVE CIRCUIT

3-3-1 Functions of solenoids

There are three solenoids in the deck; fast solenoid (L691), head base solenoid (L692), and pinch roller solenoid (L693). These solenoids have specific functions and operate in certain modes as described below.

- 1) Fast solenoid (L691)
 - This operates in the fast-forward and rewind modes to perform the following mechanical functions.
- Releasing brakes applied to the left and right reel disks.
- Disengaging the reel disk drive gear from the right-hand (takeup) reel disk and locking the intermediate pulley assembly in the fastforward position.
- 2) Head base solenoid (L692)
 - This operates in the reproduce, pause, record/ reproduce, and record/pause modes to perform the following mechanical functions.
- Raising the head base to bring the erase and record/reproduce heads into close contact with the tape.

- Lifting the pinch roller to the pause position. (The pinch roller does not press against the capstan shaft in this position.)
- Releasing brakes applied to the left and right reel disks.
- 3) Pinch roller solenoid (L693)

This operates in the reproduce and record/ reproduce modes to bring the pinch roller (raised to the pause position by the head base solenoid) into contact with the capstan to cause the tape to run at constant speed.

3-3-2 Fast solenoid drive circuit

See Fig. 3-4.

When the deck is in the stop mode, the circuit shown in Fig. 3-4 is as follows:

- * Pin 14 of U601: L level
- * Q605, Q515, Q516, Q518: off
- * Emitter of Q515: +13 V is applied via D506. During fast (fast-forward or rewind) mode, a fast mode signal (H level) is output from pin 14 of U601. This signal causes fast solenoid L691 to operate in the following sequence.
- a. As pin 14 of U601 is at H level, base current flows through transistor Q605 and turns it on.
- b. As Q605 is on, base current flows through transistor Q515 and turns it on.
- c. As Q515 is on, current flows via paths ① and ②. (The supply voltage that causes current to flow via paths ① and ② is low and therefore the current on path ① cannot energize the fast solenoid.)
- d. The current on path ② (which charges capacitor C516) causes transistor Q516 to turn on.
- e. As Q516 is on, base current flows through transistor Q518 and turns it on.
- f. As Q518 is on, current flows via paths ③ and ④. At this time, the supply voltage that causes current to flow is +39 V and therefore a large amount of current flows through the fast solenoid (via path ③) to energize it.
- g. The current on path ④ charges C516 and it stops flowing when C516 is fully charged. Since the base current of Q516 is cut off, it turns off. The time interval between the turning on of Q515 and the turning off of Q516 (i.e., the time taken to charge C516) is approximately 100 msec which is determined by the time constant of capacitor C516 and resistor R536.
- h. As Q516 is off, Q518 turns off because its base current is cut off. In this way the current on path 3 is cut off.




Fig. 3-4 Fast solenoid drive circuit

i. Current is still flowing through the fast solenoid via path ① even though path ③ is cut off. Once the fast solenoid is energized by the strong current on path ③, this weak current flowing via path ① can hold it on.

Thus a high voltage (strong drive current) is supplied to the solenoid when energizing it while a low supply voltage (weak current) hold it on. This ensures solenoid operation by generating a strong mechanical force and prevents the solenoid from heating up by reducing the holding current.

The circuit which switches the supply voltage of the solenoid is called the flashing circuit.

When a fast mode is released (the STOP button is depressed during fast-forward or rewind mode), the following sequence of operations takes place.

- j. As soon as a fast mode is released, pin 14 of U601 turns to L level.
- k. Q605 turns off, because its base current is cut off.
- As Q605 is off, Q515 turns off, as its base current is cut off.
- m.As Q515 is off, the solenoid is reset, because its holding current which was flowing via path

① is cut off. At the same time, C516 discharges via path ⑤ to prepare for the subsequent start of a fast mode.

3-3-3 Head base solenoid drive circuit See Fig. 3-5.

The head base solenoid operates during the reproduce (record/reproduce) and pause (record/ pause) modes. In the reproduce mode, a reproduce mode signal (H level) is output from pin 12 of U601. In the pause mode, a pause mode signal (H level) is output from pin 11 of U601. In both cases, the H-level signal causes base current of transistor Q601 to flow so it is turned on. The part of the head base solenoid drive circuit after Q601 is exactly the same as the fast solenoid drive circuit described in the previous section. Since these circuits operate in the same way, the description is not repeated. Note that the time during which the solenoid is energizied by the high voltage from the flashing circuit (capacitor C516 and resistor R536 determine this) is approximately 400 msec, longer than the 100 msec of the fast solenoid. The reason is to ensure operation of the head base solenoid as its mechanical load is much greater.




Fig. 3-5 Head base solenoid drive circuit

3-3-4 Pinch roller solenoid drive circuit See Fig. 3-6.

The pinch roller drive circuit (drive & flashing circuit) operates basically in the same way as the fast solenoid and head base solenoid drive circuits and, therefore, the description is not repeated. Since the mechanical load of the pinch roller solenoid is low, the flashing interval is 100 msec which is provided by capacitor C508 and resistor R521.

Here, operation of the power delay circuit and reproduce delay circuit are described as they are not incorporated in solenoid drive circuits.

1) Power delay circuit

The positive side of capacitor C526 is connected to the output of the +23 V voltage regulator. This regulated +23 V is used as the power source for the amplifiers and also as a reference voltage for the power supplies which supply the control circuits, reel motor,

and capstan motor, etc., with DC power. (These power supplies are described in 3-8-2.) When power is turned on, the tape might become slack or run unevenly if the reproduce mode is entered before the +23 V is stable. The power delay circuit delays the operation of the pinch roller until the DC supply voltage lises to a steady level after power is switched on. This circuit operates as follows.

- a. When power has been turned on, the +23 V regulated power supply starts to work and its output voltage rises.
- b. As the output voltage rises, base current flows through transistor Q521 via capacitor C526 and resistor R547, turning it on.
- c. As Q521 is on, base current flows through transistor Q508 and turns it on.
- d. As Q508 is on, the base and emitter of pinch roller solenoid driver transistor Q509

- are shorted. Therefore, base current does not flow to Q509 and it will remain off even if transistor Q602 turns on with a reproduce mode signal (H level) supplied from U601.
- e. When C526 is fully charged (in approximately 1.5 seconds) after power is switched on, the base current of Q521 stops and it turns off. (C526 and R547 provide the delay time of about 1.5 seconds.)
- f. As Q521 is off, Q508 turns off, having its base current cut off. Now Q509 is ready for operation. This process keeps the pinch roller solenoid inactive for approximately 1.5 seconds after power is switched on.

- 2) Reproduce delay circuit
 - The circuitry is designed so that, in the reproduce mode, the pinch roller solenoid operates after the head base solenoid has completed operation. The reproduce delay circuit delays pinch roller operation until the completion of the head base solenoid operation. Fig. 3-7 and 3-8 are a flowchart and timing diagram, respectively, of the process which begins with the output of a reproduce mode signal (H level) from pin 12 of the system control IC and ends with the energizing of the pinch roller solenoid. In Fig. 3-7, operations of the reproduce delay circuit are enclosed in bold boxes.




Fig. 3-6 Pinch roller solenoid drive circuit




Fig. 3-7 Flowchart of solenoid operation (in reproduce mode)




Fig. 3-8 Timing diagram of solenoid operation (in reproduce mode)

3-4. REEL MOTOR DRIVE CIRCUIT 3-4-1 Direction of motor rotation

The reel motor drives the left or right reel disk to take up the tape. Torque is transmitted from the reel motor to one of the reel disks during the reproduce, fast-forward, and rewind modes by the processes shown in Fig. 3-9 — 3-11 (as seen from the front of the deck). As seen from Fig. 3-9 and 3-11, the reel motor rotates in the same direction during the reproduce and rewind modes and the fast-forward pulley mechanically selects either the left or right reel disk and drives it in accordance with the direction of reel motor rotation. In the pause mode, the reel motor does not rotate.




Fig. 3-9 Reel disk drive (reproduce mode)




Fig. 3-10 Reel disk drive (fast-forward mode)




Fig. 3-11 Reel disk drive (rewind mode)

3-4-2 Reproduce mode

See Fig. 3-12.

When the deck is in the stop mode, base current is supplied to transistor Q505 via R510, turning it on. In the reproduce mode, the reel motor rotates in the following sequence.

- a. When a reproduce mode signal (H level) is output from pin 12 of U601, Q601 and Q602 turn on.
- b. Q601 activates the head base solenoid drive circuit. When the head base solenoid completes operation, Q508 turns off, permitting base current to flow through Q509 and turning it on.
- c. As Q509 is on, base current flows through Q501 and turns it on. At the same time, current flowing via path ① charges capacitor C504.
- d. As Q501 is on, base current flows through transistor Q504 via path 2 and turns it on.
- e. As Q504 is on, current is supplied to the reel motor via path ③ and causes the motor to run. At this time, the supply voltage of +13 V is directly applied to the reel motor so that the motor drives the reel disk with a large starting torque so that the tape is tight.
- f. As current on path ① charges C504 and its charge rises, the voltage at the base of Q506 rises and its base current increases; Q506 is turned on completely in about 80 msec. Now the base current of Q505 decreases since its base level falls from +13 V, divided by R510

and R509. This results in a decrease in Q505's collector current (the current supplied to the motor) and in the voltage applied to the motor. Thus the torque of the motor is reduced and the reproduce mode is stabilized.

3-4-3 Rewind mode

See Fig. 3-12.

When the rewind mode has been enabled, a rewind mode signal (H level) is output from pin 13 of U601 and base current flows through Q501 via resistor R622, turning on Q501. Q504 turns on immediately since its base current flows along path ② . When Q504 is on, a large current is supplied to the reel motor via path ③ , driving the motor at a high speed. During the rewind mode, Q506 remains off.

3-4-4 Fast-forward mode

See Fig. 3-13.

When the fast-forward mode has been enabled, a fast forward mode signal (H level) is output from pin 15 of U601 and base current of transistor Q502 flows via resistor R620, turning Q502 on. As Q502 is on, base current of transistor Q503 flows via path ①, turning Q503 on. Now +13 V is applied to the reel motor, the large current flowing via path ② causes the motor to run at a high speed. The direction of the current is reversed in the fast-forward mode to that in the reproduce and rewind modes so the direction of motor rotation is reversed.




Fig. 3-13 Reel motor drive circuit (fast-forward mode)




Fig. 3-12 Reel motor drive circuit (reproduce/rewind modes)

3-5. CAPSTAN MOTOR CIRCUIT See Fig. 3-14.

The capstan motor rotates in the reproduce (record/reproduce) and pause (record/pause) modes. Its torque is transmitted to the flywheel by a belt to drive the flywheel and capstan shaft. In both the reproduce and pause modes, Q514 is on to energize the head base solenoid. When Q514 is on, base current flows through transistor Q692, turning it on. Now the 0 V line of the capstan motor servo amplifier is shorted to the ground line of the power supply circuit. The servo amplifier is activated and the motor starts to rotate. The speed of the capstan motor may be switched between 'standard' (tape speed: 4.76 cm/sec) and 'high' (9.5 cm/sec) by SPEED switch S4-2.

3-6 TAPE-END DETECTION CIRCUIT See Fig. 3-15.

The ring magnet, shown in Fig. 3-15, is mounted on the counter pulley shaft and rotates while the tape is running. Variations in the magnetic field caused by the rotation of the ring magnet turn reed switch S693 on and off. This means that, when the tape is moving, the reed switch turns on and off repeatedly.

When the reed switch turns on while the tape is running, the charge from capacitor C609 flows through the base of transistor Q607 via path ③, turning it on. When the reed switch turns off, Q607 turns off, as its base current is cut off. At this time, C609 discharges via path ④. Thus, while the reed switch is turning on and off repeatedly, Q607 also turns on and off repeated-




Fig. 3-14 Capstan motor circuit

ly. When Q607 is off, capacitor C610 is charged by current flowing via path 5. When Q607 is on, C610 discharges via path 6. Since the time constant of C610 and R631 is much smaller than that of C610 and R656 (or R657), the charging of C610 proceeds slowly while it discharges rapidly. As a result, the voltage at A remains below +1.5 V while Q607 is repeatedly turned on and off.

When the tape reaches its end and stops running, the counter pulley and the ring magnet stop rotating. At this time, the reed switch stops operating in either its on or off position depending on where the ring magnet has stopped. If the reed switch is on, the base current of $\Omega607$ stops flowing turning it off, and current flowing along path 3 starts to charge C610 as soon as

current from path ③ completes charging C609. If the reed switch is off, Q607 is already off because the reed switch has turned off and, therefore, current from path ⑤ continues to charge C610.

When the voltage across C610 (voltage at A) exceeds approximately 3 V, base current flows through transistor Q513 via path T, thereby turning on Q613. Q613 turns on approximately 2.3 seconds after Q607 turns off. Since Q613 turning on is equivalent to depressing the stop button, the deck enters the stop mode.

When the deck enters the stop mode, current on path ① or ② stops flowing and C610 discharges via R656 and the fast solenoid and via R657 and the pinch roller solenoid (current flows in the direction opposite to ⑤).




Fig. 3-15 Tape-end detect circuit

3-7. MEMORY CIRCUIT

See Fig. 3-16.

Counter switch S696 is linked to the counter and is closed when the counter reads between "900" and "999".

- a. When the deck is in the rewind mode, a rewind mode signal (H level) is output from pin 13 of system control IC U601.
- b. Therefore, current flows from pin 13 of U601 to charge C507 via R502 and R518. Charging takes place slowly because of the large charging time constant.
- c. The counter counts down as the tape is rewound and, when it reaches "999", S696 turns on.
- d. When S696 turns on, C507's charge flows to the base of Q691 via S696 and R691, turning Q691 on.
- e. If the MEMORY switch is set to STOP when Q691 has turned on, a stop signal (L level) is output from pin 2 (and pin 4) of U601 and the deck enters the stop mode.
- f. Pin 4 (MEMO IN) of U601 has the function that, if it becomes L level when U601 is in the rewind mode, the rewind mode will be released and the stop mode enabled. In the deck, this terminal is connected to the STOP IN terminal.
- g. If the MEMORY switch is set to OFF, the collector of Q691 is open and S696 is on. The tape will be rewound to the end and, when the tape-end detect circuit detects the tape end, the deck will enter the stop mode automatically.

- h. If the MEMORY switch is set to PLAY when Q691 has turned on, a reproduce mode signal (L level) is output from pin 1 of U601 and the deck enters the reproduce mode.
- The stop mode is entered automatically when the tape has been rewound to the end before the counter reaches "999", whether the MEMORY switch is set to STOP or to PLAY.

3-8. POWER SUPPLY CIRCUITS

3-8-1 Main regulator

See Fig. 3-17.

Transistors Q517, Q519, Q520, and zener diode D512 are the main components of the main regulator. The output of the main regulator is supplied to the amplifiers and also used as a reference voltage in the regulated power supplies of the motor and control circuits.

- 1) Equilibrium condition
 - a. The secondary voltage of the power transformer is full-wave-rectified by rectifiers D541 – D544, then smoothed by capacitor C520.
 - b. When power is not supplied to the regulated power supplies, Q517, Q519, and Q520 are off. (Q519 is the current amplifier that controls Q517 by amplifying variations of weak control current flowing through Q520 described later. Here, the operation of Q519 is not described.)
 - c. When the power supply to the regulated power supplies starts, the base current of Q517 flows via path ①. Since Q520 is still off at this time, current flowing




Fig. 3-16 Memory circuit

through resistors R540 and R541 are input to the base of Q517, permitting a large collector current ② to flow through Q517. As a result, the output voltage rises rapidly.

- d. As the output voltage rises, current flows via paths ③ and ④. The emitter of Q520 is fixed at the zener voltage (VZD ÷ 13 V) by current flowing along path ③ and the zener diode.
- e. If the output voltage rises for any reason and the current flowing along path 4 increases, the voltage drop across R544 increases and the base voltage of Q520 rises. When the base level exceeds the emitter level, collector current 5 begins to flow to Q520.
- f. The output voltage of the main regulator has been rising during this time. However, the collector current of Q520 works to reduce the output voltage because the current on path ① decreases.
- g. When the voltage difference between the base and emitter of Q520 reaches approximately 0.7 V, the main regulator enters a state of equilibrium. That is, drift of the current on path ① tending to raise the output voltage is cancelled by the tendency to reduce the output voltage because a rise of the output voltage results in an increase in the current of Q520, an increase of the current on path ⑤ , and a decrease of the current on path ① in this sequence.

h. In the state of equilibrium, the output voltage is determined by the following equation.

$$\frac{R544}{R542 + R544} \times V_{OUT} = V_{ZD} + V_{BE}$$

$$\therefore V_{OUT} = \frac{R542 + R544}{R544} \times (V_{ZD} + V_{BE})$$

Substituting the actual values of the circuit parameters, we have the output voltage as follows.

$$V_{OUT} = \frac{4.7k\Omega + 6.8k\Omega}{6.8k\Omega} \times (13 + 0.7) \div 23.1 \text{ V}$$

2) Regulating process

When the output voltage tends to rise (fall) because of reduced (increased) load, the following process stabilizes the voltage.

- a. The output voltage starts to rise (fall).
- b. The base level of Q520 rises (falls).
- c. Since the emitter of Q502 is kept at a fixed level, its base current increases (decreases) and the collector current (5) varies together with rising (falling) of the base level.
- d. As a result, the base current ① of Q517 decreases (increases) and its collector current varies similarly.
- e. Thus the output voltage falls (rises) to the initial level.




Fig. 3-17 Main regulator

3-8-2 DC power supply system

The DC power supply system is shown in Fig. 3-18. This comprises the main regulator described in the previous section and minor regulated power supplies from independent transistors Q512, Q513, and Q507. For these transistors, the +23 V regulated output of the main regulator is used as a reference voltage to simplify the circuitry.

The output voltages of the minor power supplies are roughly given by the following equations:

$$V_{OUT (Q512)} = \frac{R527}{R526 + R527} \times (+23V) - V_{BE}$$

$$V_{OUT (Q513)} = \frac{R530}{R529 + R530} \times (+23V) - V_{BE}$$

$$V_{OUT (Q507)} = \frac{R515}{R514 + R515} \times (+23V) - V_{BE}$$
where V_{BE} is $0.6 - 0.7 \ V$.

arti chapana favol sagu oni




Fig. 3-18 DC power supply system




Fig. 3-19 Schematic of reproduce mode

3-9. OVERALL OPERATION OF THE DECK

We have so far seen the separate operations of control circuits, each with a specific function. This section briefly describes the overall operation of the deck operations in the reproduce, pause, fast-forward, and rewind modes. Refer to Section 3-10-3 for operation in the record mode.

3-9-1 Reproduce mode

See Fig. 3-19.

To explain operations in the reproduce mode, we divide the system into two subsystems. One is the head base subsystem that operates when Q601 is turned on by the H-level signal output from pin 12 of U601. The other is the pinch roller subsystem that operates, when Q602 is turned on.

1) Head base subsystem

This goes through the following steps when Q601 is turned on.

- a. The head base solenoid operates.
- b. A delay signal is applied to the pinch roller solenoid drive circuit via the flashing circuit of the head base solenoid.
- c. Q692 turns on and the capstan motor rotates.

2) Pinch roller subsystem

This goes through the following steps after a delay long enough for the operation of the head base solenoid following the turning on of Q602.

- a. The pinch roller solenoid operates.
- b. The reel motor rotates.
- c. The tape-end detection circuit becomes ready for operation.
- d. Q614 turns on and the reproduce amplifier is released from muting.

3-9-2 Pause mode

To explain operations in the pause mode, we divide the system into the head base subsystem (as in the reproduce mode) that operates, with $\Omega601$ turned on by the H-level signal output from pin 11 of U601, and the indicator subsystem that causes the PAUSE indicator to light when $\Omega603$ is on.

3-9-3 Fast-forward mode

In the fast-forward mode, we divide the system into the fast-forward subsystem that operates when an H-level signal is output from pin 15 of U601 and the fast subsystem that operates when an H-level signal is output from pin 14 of U601.

1) Fast-forward subsystem


The reel motor rotates.

- 2) Fast subsystem
 - a. The fast solenoid operates.
 - b. The tape end detection circuit becomes ready for operation.

3-9-4 Rewind mode

In the rewind mode, we divide the system into the rewind subsystem that operates when a Hlevel is output from pin 13 of U601 and the fast subsystem that operates when a H-level is output from pin 14 of U601.

- 1) Rewind subsystem
 - a. The reel motor rotates.
 - b. The memory circuit becomes ready for operation.
- 2) Fast subsystem
 - a. The fast solenoid operates.
 - b. The tape-end detection circuit becomes ready for operation.






Fig. 3-21 Schematic of fast-forward mode




Fig. 3-22 Schematic of rewind mode

3-10. MUTING CIRCUITS 3-10-1 Power muting circuit See Fig. 3-23.

The power muting circuit prevents transient click noise from being output from the OUT-PUT and PHONES terminals and the VU meter needles from deflecting when the deck's power switch is turned on or off.

1) Power-on muting

When the deck power switch has been turned on, the power muting circuit operates as follows.

- a. When power has been turned on, the power muting circuit is supplied with 7 V AC. Diodes D516 and D515 half-wave-rectify the AC voltage, charging capacitors C524 and C523 via paths ① and ② momentarily. The voltage across C523 is divided by resistors R551 and R550 and is then applied to the emitter of transistor Q522.
- b. Capacitor C522 serves as a ripple filter together with R551.
- c. The charging of C521 starts via paths 3 and 4 when the circuit's power supply starts. Since the current on path 4 is the base current of transistor Q522, it turns on.
- d. As Q522 is on, base current flows through transistor Q104 via path (5), turning it on.

- As Q104 is on, the signal line of the monitor circuit is shorted to ground to prevent the generation of click noise when power is switched on.
- e. When C521 is fully charged, Q522 turns off as its base current is cut off. Q104 turns off in the same way and, as a result, muting is released.

Releasing power muting takes place approximately 3.5 seconds after the deck power switch is turned on.

f. When Q522 is off, -5.3 V is applied to the based of Q104 via R128 and R553. This ensures the off state of Q104.

2) Power-off muting

When the deck power switch has been turned off, the power muting circuit operates as follows.

- a. When power has been turned off, the supply of 7 V AC stops. C524 and C521 discharge rapidly through the meter lamp circuit via paths (6) and (7).
- b. Therefore, the base voltage of Q522 falls and its base current flows from C523 via path (8), turning it on.
- c. As Q522 is on, C523 discharges via path
 (9), turning on Q104 so that the power amplifier is muted.




Fig. 3-23 Power muting circuit

3-10-2 Reproduce muting circuit See Fig. 3-24.

The reproduce muting circuit mutes the reproduce equalizer amplifier to prevent the generation of undesirable noise in modes other than the reproduce mode.

1) Muting on

In a mode other than the reproduce mode (stop mode, for example), the reproduce muting circuit operates as follows to mute the reproduce equalizer amplifier.

- a. In the stop mode, the pinch roller solenoid drive transistor Q509 is off.
- b. Because of this base current is not supplied to transistor Q614 and it remains off.
- c. As Q614 is off, base current of Q113 flows via path 1, therefore it is on.
- d. As Q113 is on, base current of Q112 flows via path ② and it is on. At this time, capacitor C136 is charged to +23 V.
- e. As Q112 is on, the base current of Q103 flows via path ③ and it is on so the reproduce equalizer amplifier is muted. Because the signal level is low in the Q103 circuit its collector is grounded to reduce muting transistor switching noise.

2) Muting off

When pinch roller solenoid drive transistor Q509 turns on in the reproduce mode, muting is released by the following process.

- a. As Q509 is on, base current is applied to Q614 and it turns on.
- b. As Q614 is on, Q113 turns off as its base current 1 is cut off.
- c. When Q113 is off, the base current ② applied to Q112 is cut off. Q112 does not go off immediately since C136's discharge current ④ flows to its base.
- d. As C136 discharges, its discharge current ④ (the base current of Q112) decreases gradually, causing the collector current of Q112 to decrease gradually. Therefore, the base current of Q103 decreases and it goes off gradually.
 - Q103 turns off approximately 400 msec after Q509 is turned on.
- e. Once Q112 turns off, the base of Q103 is fixed at a negative voltage applied through R150 to lock it in the off state. Reproduce muting is completely released in this condition.




Fig. 3-24 Reproduce muting circuit

3-10-3 Record muting circuit

See Fig. 3-25.

Record inhibit switch S694 operates by mechanically detecting the presence or absence of a record protection tab on the cassette loaded in the deck.

S694 is in the N.O. position if the loaded cassette is protected by the tab being removed. In this case, pin 9 (AR IN) of system control IC U601 is fixed at L level. The deck will not enter the record/reproduce mode when the PLAY and RECORD buttons are depressed simultaneously if terminal AR is at L level. (The reproduce mode will be enabled in this case.)

S694 switches to N.C. when a recording-enabled cassette tape (i.e. protection tab not removed) is loaded. Now current from U601 charges capacitor C607 and terminal AR switches to H level. When terminal AR is at H level, recording can occur. Hereafter it is assumed that terminal AR is at H level.

1) Record/reproduce mode

When the deck is in the stop mode, the circuits shown in Fig. 3-25 are in the following conditions.

Pins 12 and 10 of U601: L level

Transistors: Q604, Q609, Q612, Q114, and

Q115: off

Transistors: Q608, Q610, Q611, Q110, and

Q111: on

Record muting Q116: on Record muting flip-flop: reset Bias oscillator U103: not oscillating

If the PLAY (>) and RECORD buttons have been depressed simultaneously, H-level signals are output from pins 12 and 10 of U601. The reproduce mode signal output from pin 12 is mainly for the control of mechanical tape transport operations (see 3-9-1). The record mode signal output from pin 10 initiates the following operations.

- a. When an H-level signal is output from pin 10 of U601, base current flows through Q604 and it turns on. As Q604 is on, current flows through the RECORD LED and turns it on. At the same time, Q611 turns off as its base current is cut off.
- b. As Q611 is off, Q610 turns off as its base current is cut off. Similarly Q111 turns off, as its base current is cut off.
- c. As Q111 is off, discharge current from C135 flows through the loop consisting of C135, the emitter of Q110, the base of Q110, and C135. As the discharging of C135 proceeds, the discharging current (the

base current of Q110) decreases and Q110 turns off slowly.

- d. As Q110 turns off gradually, the base current of Q116 decreases gradually and it is turned off slowly. As a result, the record amplifier is smoothly released from muting.
- e. On the other hand, if an H-level signal is output from pin 10 of U601, base current flows through Q115 and it turns on. Therefore, base current is applied to Q114 turning it on.
- f. When Q114 has turned on, bias oscillator Q103 begins to oscillate, its output being delivered to the erase head. At the same time, it is added to the output signal (audio signal) from the record amplifier after its level has been adjusted by the bias adjust circuit and the resulting signal is supplied to the record head.

2) REC/MUTE mode

If you depress the REC MUTE button when the deck is in the record/reproduce mode, the recording signal is muted to leave a blank section on the tape.

When the deck is in the record/reproduce mode the circuits shown in Fig. 3-25 are as in the following condition.

Pins 12 and 10 of U601: H level

Transistors: Q604, Q608, Q114, and Q115:

on

Transistors: Q609-Q612, Q110, Q111, and

Q116: off

REC MUTE flip-flop: reset Bias oscillator: oscillating Record muting: released

If the REC MUTE button has been depressed in the record/reproduce mode, the circuits operate as described below to enable the REC/MUTE mode.

- a. When the REC/MUTE button has been depressed, the REC MUTE flip-flop is reset by an L-level signal. Q608 turns off as its base current is cut off.
- b. As Q608 is off, its collector rises to H level and base current flows through Q609 turning it on. When Q609 is on, its collector is at L level. Therefore, if the REC MUTE button is released and the L-level signal is removed from the REC MUTE flip-flop, Q608 stays off and Q609 on.
- c. As Q609 is on, base current flows through Q610, turning it on. When Q610 turns on, Q111, Q110, and Q116 turn on in sequence, as opposed to on in the record/ reproduce mode, and the record amplifier




Fig. 3-25 Record muting circuit

29

is muted. Since the bias oscillator is working at this time, the tape runs with no signal recorded on it.

d. On the other hand, when Q610 turns on, base current flows through Q612, turning it on (Q611 is off during record mode). When Q612 turns on, the REC MUTE LED lights.

The REC/MUTE mode is released by resetting the REC MUTE flip-flop. There are three ways this can be done as below.

- i) Depress the PLAY button. An L-level reset signal will be applied to the base of Q609 via path ①.
- ii) Depress the PAUSE button. When the PAUSE button has been depressed, the deck changes from the record/reproduce (mute) mode to the record/pause mode. Therefore, pin 12 of U601 changes from H level to L, applyings L level signal to the base of Q609 via path ②.
- iii) Depress any of the STOP, F.FWD, and REW buttons.

The record/reproduce (mute) mode will be released and pins 12 and 10 of U601 drop to L level. As a result, a reset signal will be applied to the base of Q609 via path ② or ③.

When an L-level reset signal has been applied to the base of Q609, Q609 turns off as its base current is cut off. Since the collector of Q609 rises to H level, base current flows through Q608 and it turns on resetting the REC MUTE flip-flop. When Q609 is off, Q610 turns off as its base current is cut off. (Note: In this case, the base current of Q608 flows via path 4. The voltage drop across R647 caused by this current (the emitter-base voltage of Q610) is approximately 0.16 V so Q610 cannot turn on.) When Q610 has turned off, Q111, Q110, and Q113 turn off in sequence to release the record amplifier from muting. Note that, when the STOP, F.FWD, or REW button is depressed during REC/ MUTE mode (case (iii)), the record mode will be released. In this case, when pin 10 of U601 drops to L level, Q604 turns off as its base current is cut off, while Q611 turns on as base current is applied to it. Therefore, even if Q609 turns off with the REC MUTE flip-flop reset, Q610 remains on because its base current flows via R648 and Q611. This means that the record amplifier is not released from muting.

AMPLIFIER SECTION 3-11. REPRODUCE CIRCUIT

See Fig. 3-26.

a. The signal picked up by the reproduce head is amplified by reproduce equalizer amplifier transistors Q101 and Q102. The reproduce equalizer amplifier negative feedback loop determines the compensation characteristic (time constants) for reproduction as given in Table 1. The compensation curve at high frequencies is determined by the composite resistance of R301—R304, the combination of which is determined by the settings of SPEED switches S4-10 and S4-8 and EQ switch S5-2, and the capacity of C104. Table 2 summarizes the composite resistances in relation to the settings of the SPEED and EQ switches.

Table 1
Compensation characteristic for reproduction

SPEED	STANDARD	HIGH	
METAL	3180 + 70	3180 + 35	
Co (CrO ₂)	3180 + 70	3180 + 35	
NORMAL	3180 + 120	3180 + 50	

(unit: µsec)

Table 2 Composite resistance

SPEED	STANDARD	HIGH
METAL	R302 = 6.2k	R301//R302 =3.1k
Co (CrO ₂)	R302 = 6.2k	R301//R302 ÷3.1k
NORMAL	R302 + R304 =10.9k	R301//R302 + R303//R304 +4.2k

("//" represents parallel connection of resistors. unit: ohms)

- b. Capacitor C107 and coil L101 connected in series are a bias trap with a resonance frequency of 100 kHz.
- c. Semi-fixed resistor R11 adjusts reproduction level.
- d. Capacitor C108 and semi-fixed resistor R10 compensate for characteristics at high frequencies.
- e. Thermistor RT10 compensates for variations in the sensitivity of the reproduce head due to temperature changes.

The standard resistance of RT10 is 10k ohms at room temperature (25°C). The resistance decreases (increases) when the temperature rises (falls). On the other hand, the sensitivity of the reproduce head rises

(falls) when the temperature rises (falls). If the sensitivity of the reproduce head has risen due to a rise in temperature, for example, the output level of the reproduce equalizer amplifier increases. But the resistance of the thermistor drops at the same time and, therefore, the input level of Dolby decoder U101 drops. As a result, the input level of U101 remains constant and is independent of the temperature.

f. In the Dolby decoder, L102 and C112 form a low-pass filter with a cutoff frequency of approximately 22.5 kHz. L103 and C113 form a band-elimination filter. These filters remove undesirable frequency components outside the audio range which might cause incorrect operation of the Dolby decoder.




Fig. 3-26 Reproduce circuit

3-12. MONITOR CIRCUIT

See Fig. 3-27.

The tape reproduce signal or source signal selected by MONITOR switch S2-5 is distributed to

three lines: the output circuit, phone amplifier, and meter amplifier. The output of the meter amplifier is sent to the VU meter circuit and peak indicator circuit.




Fig. 3-27 Monitor circuit

3-12-1 Output circuit

The monitor signal selected by the MONITOR switch is output to the OUTPUT terminal via resistor R127 and OUTPUT control R34.

The rated output level at the OUTPUT terminal is -7 dB when the level at TP1 is 580 mV (Dolby level). At this time the VU meter reads +3 VU.

3-12-2 Phone amplifier

The deck is provided with PHONES control R73. This allows the headphone monitor level to be varied independently of the VU meter reading and the output level at the OUTPUT terminal. The maximum output of the phone amplifier is 100 mW into an 8-ohm load.

3-12-3 Meter circuit

1) Meter sensitivity switching circuit

The bias and equalization of the deck are adjusted for suitability with different types of tape. In addition, the deck is provided with a BIAS/REC calibration circuit that allows bias to be adjusted to the most suitable value for the individual tape used to optimize tape performance. When adjusting bias and recording level using this circuit the signal input level at the LINE 1 terminal is -30 dB, which is 20 dB lower than the rated input level of -10 dB. This low level would not normally be read by the VU meter, so a circuit which increases meter sensitivity during adjustment is provided.




Fig. 3-28 Peak indicator circuit

When INPUT switch S1-1 is set to LINE 1 or LINE 2, base current flows through Q701 and it is on. As Q701 is on, resistor R702 is inserted in parallel to the input circuit of the meter amplifier. This setting provides the standard meter sensitivity.

When the INPUT switch is set to TEST and the deck is in the record/reproduce or record/pause mode, Q701 is off as its base current is cut off. When Q701 is off, R702 is disconnected from the input circuit of the meter amplifier. As a result, the signal input level of the meter amplifier rises by about 20 dB. This rise in the input level results in a rise of the output level by the same amount so that meter sensitivity is raised by 20 dB.

2) Peak indicator circuit

See Fig. 3-28 and 3-29.

Semi-fixed resistor R72 determines the operating level of the peak indicator.

When the signal level supplied from the meter amplifier is lower than the threshold level of Q704 determined by R72, the condition of the circuit shown in Fig. 3-28 is as follows. Q704: off


C708: charged

Pins 12 and 13 of U701: H level Pins 11, 9, and 10 of U701: L level

Pin 8 of U701: H level Peak indicator: off

When a high-level, pulse-like signal is output from the meter amplifier, the circuit operates as follows.

a. When the input signal level exceeds the threshold level of Q704 determined by R72, base current flows to Q704 and it turns on.



* WHEN VOLTAGE AT (B) IS VIEWED AS LOGIC LEVEL.

Fig. 3-29 Peak indicator circuit timing diagram

- b. When Q704 turns on, its collector drops to L· level and C708 discharges momentarily. Therefore, pin 13 of U701 drops to L level. This inverts gate A, causing a H level at pin 11 of U701. After inversion by gate B, an L level occurs at pin 8 of U701.
- c. When pin 8 of U701 has dropped to L level, current flows through the PEAK LED and the peak indicator lights.
- d. Alternately, the L level at pin 8 of U701 is transmitted to pin 12 of U701 via resistor R716. If R716 is open, pin 12 of U701 would not fall to L level when the collector of Q704 has dropped to L level because of the presence of diode D703. In this case, operation would not be stable.
- e. When the input level falls below the threshold level of Q704, its base current stops, turning it off.
- f. When Q704 has turned off, current flows into C708 via R715 to charge it. The voltage across C704 (the voltage at ®) rises as shown in Fig. 3-29.
- g. When the voltage at ® has risen to a certain level (E1: approx. +2.0 V), U701 regards the input at pin 13 as H level. Waveform © represents the voltage at ® as logic level.
- h. When the charging of C708 proceeds and the voltage at ® reaches E2 which is approximately 0.6 V higher than E1 (forward voltage drop of D703), U701 regards the input at pin 12 as H level. At this moment, gate A is inverted since pins 12 and 13 of U701 are both H level, and the output from pin 11 of U701 drops to L level.
- Therefore, gate B is also inverted and the output of U701 pin 8 turns to H level. As a result, current supplied to the PEAK LED is cut off and the peak indicator goes out.

As described above, the peak indicator circuit incorporates a pulse stretching function that keeps the peak indicator lit for a certain length of time even when the duration of the input signal is very short.

3-13. RECORD CIRCUITS 3-13-1 Line input circuits See Fig. 3-30.

The deck has two line input circuits. LINE 1 is provided at the back of the deck and LINE 2 on the front panel. The INPUT switch determines which line input is used. Signals from the LINE 1 and LINE 2 input terminals cannot be mixed. To use the BIAS/REC calibration circuit, set the INPUT switch at TEST and apply input signals to the LINE 1 terminals.

With its level adjusted by the RECORD volume control, the line input signal selected by the INPUT switch is sent to Dolby encoder U301.

MPX filter U305 connected to U301 removes subcarrier and pilot signals which are mixed with line input signals when recording FM broadcasts in order to prevent the Dolby encoder from mis-operation. The MPX filter operates only when transistors Q301 and Q302 are both on. When they are off, the signals simply pass through the filter. Q301 and Q302 are on only when the NR SYSTEM switch is set to NR or NR+HX: that is, when U301 is operating as an encoder.

Whatever the position of the NR SYSTEM switch, an unmodified input signal is output from pin 3 of U301 to the monitor circuit.

When the NR SYSTEM switch is set to NR or NR+HX, an encoded signal is output from pin 7 of U301. When the switch is at OUT, an unmodified input signal is output. The output from pin 7 is input to the line amplifier via the HX variable equalizer. (Refer to 3-14 for the HX variable equalizer.)

3-13-2 Line amplifier

See Fig. 3-31.

Recording level adjusting circuit BIAS/REC CALIBRATION is included in the input circuit of the line amplifier. When the CALIBRATION switch is set at ADJUST, the recording level can be adjusted with semi-fixed resistor R30. At this time ADJUST LED D1 lights.

A temperature compensation circuit comprising thermistor RT11 is located in parallel with the output line of the line amplifier.

The output of the line amplifier is sent to the recording level adjusting circuit after the record signal level has been adjusted to match the type of tape being used.




Fig. 3-30 Line input circuit




Fig. 3-31 Line amplifier

3-13-3 Record amplifier

See Fig. 3-32.

The output of the line amplifier is sent to the record amplifier comprising transistors Q117 and Q118. The record amplifier adjusts the recording signal depending on the speed and type of tape. The recording equalization characteristics are determined by the LC resonance circuit and CR circuit connected to the emitter of Q117. Because of this, a complementary circuitry consisting of NPN (Q117) and PNP (Q118) transistors is used in the record amplifier for more efficient operation requiring less voltage.

Resistor R176 raises the output impedance (impedance of the signal source viewed from the record head) of the record amplifier to drive the record head with constant current.

The parallel resonance circuit of L104 and C144 is a bias trap with a resonance frequency of 100

kHz. At the resonance frequency, the impedance of the resonance circuit becomes infinitely large, preventing bias current from entering the record amplifier (if this should happen, the amplifier would be saturated and the signal distorted). The record signal output from the record amplifier passes through the bias trap and, after the addition of bias current, drives the record head. Bias current is supplied by bias oscillator U103. When the BIAS/REC CALIBRATION switch S7-2 is set to PRESET, the record head is supplied with bias current adjusted by R13, R14, or R15 according to the setting of BIAS switch S6-2 for the type of tape being used. When S7-2 is at ADJUST, bias can be adjusted by turning semi-fixed resistor R35 which is accessible from the front of the deck. The supply voltage of the bias oscillator is controlled by the Dolby HX circuit. The circuit that controls the supply voltage is described in 3-14.




Fig. 3-32 Record amplifier

3-14. DOLBY HX CIRCUIT

NOTE: The Dolby Headroom Extension system
(Dolby HX system) is provided in the record circuit of the deck and operates only in the following conditions.

NR SYSTEM switch: NR + HX
SPEED switch: STANDARD
BIAS switch: Co (CrO₂) or NORMAL
EQ switch: Co (CrO₂) or NORMAL
Mode: record/reproduce mode

3-14-1 Bias characteristics

Generally tape has the bias characteristic as shown in Fig. 3-33. In the bias characteristic, (relationship of bias current to record/reproduce level) of a record signal of 315 Hz, for example, the record/reproduce output level rises with bias current and it reaches maximum at the maximum sensitivity bias current (peak bias). If bias current increases further the record/reproduce output level falls gradually. On the other hand, distortion is diminished as bias current increases. The variation of output level with bias current follows a relatively gentle curve at low frequencies but is steep at high frequencies. The output level at peak bias falls as the frequency becomes higher.

For tape having specific bias characteristics, major factors determining bias current are sensitivity, distortion, and frequency response.

Normally bias is determined in the following way. In the frequency spectrum of music signals which are most commonly recorded low and middle frequency components dominate and the spectrum drops steeply at high frequencies. Conventionally bias was determined by taking mainly sensitivity and the distortion of bass and mid-range components into consideration, sacrificing frequency response at high frequencies.

However, for maximum sensitivity at bass and mid-range frequencies, bias should be much higher than at high frequencies. Therefore, strong equalization is required for recording high frequencies. (Fig. 3-33 and 3-34 show recording equalization for 10 kHz at peak bias of 315 kHz.) When equalization during recording is too great, tape tends to be saturated by highfrequency components when the recording level is high or when the signals include many highfrequency components. This results in an increase in distortion and a degradation of frequency response (see Fig. 3-35). When bias is too low, the recording magnetic field becomes wider and, therefore, demagnetization increases at high frequencies. This phenomenon becomes

more noticeable with higher signal levels. Therefore, demagnetization causes the frequency response at high frequencies to diminish as the recording level increases.

From the above facts, we determined that bias must be relatively small in order to improve frequency response at high frequencies, especially for high-level, high-frequency signals.




Fig. 3-33 Tape bias characteristics (1)




Fig. 3-34 Recording compensation characteristics (1)




Fig. 3-35 Recording frequency response (1)

3-14-2 System outline

To improve the frequency response at high frequencies, especially for high-level, high-frequency signals, the Dolby HX system automatically controls bias and recording equalization for optimum levels with respect to the level of recording input signal and the relative amount of high-frequency components.

1) Bias

- a. When bass and mid-range components dominate in the input signal or the overall level of the input signal is low, a fixed high bias is applied. (See A in Fig. 3-36.) In this case, frequency response at low frequencies can be improved by selecting a bias more suitable for lower frequency content than the conventional fixed bias.
- b. When the input signal involves high-level, high-frequency components, bias is decreased instantly depending on the frequency components and level, increasing the sensitivity at high frequencies. (See ® in Fig. 3-36.)

2) Record equalizer

The Dolby HX system not only controls bias as described above but also recording equalization. This is because tape sensitivity varies at high frequencies, accompanying the change in bias.

- a. When bass and mid-range components dominate the input signal and bias is selected as (A) in Fig. 3-36, tape sensitivity is low at high frequencies and, therefore, the recording equalization is that of curve (A) shown in Fig. 3-37. With curve (A), the amount of boost at high frequencies is very large but the level of high-frequency components of the input signal is low. Therefore, distortion will not occur during recording.
- b. With high-level, high-frequency signals, bias is lowered. (See B in Fig. 3-36.) With lower bias, tape sensitivity increases at high frequencies and the amount of recording equalization may be reduced, as shown by curve B in Fig. 3-37.

Reduction in the amount of recording equalization, i.e. boost, results in expanding the headroom of the tape saturation level of high-frequency signals. (This is the origin of the name of Dolby Headroom Extension system.) As a result, frequency response at high frequencies is greatly improved (see Fig. 3-38.) and at the same time, distortion at high frequencies is minimized.




Fig. 3-36 Tape bias characteristic (2)




Fig. 3-37 Recording equalization characteristic (2)




Fig. 3-38 Recording frequency response (2)

3-14-3 Circuits See Fig. 3-39.

There are three circuits that control the recording bias and equalization characteristics, depending on the spectrum of the input signal. These are the control signal circuit, the variable bias circuit, and the variable equalizer.

1) Control signal circuit

The recording bias and equalization characteristics must be varied in accordance with high-frequency components of the input signal and their level. For this purpose, it is necessary to generate a signal which controls them, which is done by detecting and measuring high-frequency components in the input signal and their level.

In the Dolby B-type processor (as used in the M122), the noise reduction control signal is generated from the same parameters as those used by the Dolby HX system. This signal is taken from pin 14 of Dolby NR IC U301 (U401) and supplied to buffer amplifiers U303-a_and U303-b.

- a. U303-a and U303-b select and output the higher of the two input signals without permitting the Dolby processors of the left and right channels to interfere with each other.
- b. The output of the buffer stage is applied to pin 12 of high-gain, non-inverting amplifier U303-c. Generally the DC output voltage of this amplifier rises together with the DC input voltage. A DC bias voltage adjusted by semi-fixed resistor R36 or R37 is applied to pin 13 of U303-c. This voltage determines the threshold of the control voltage where the recording bias begins to decrease due to high-frequency components contained in the recording input signal. The threshold varies with the type of tape; R36 adjusts for 'normal' tape while R37 adjusts for 'Co (CrO₂)' tape.
- c. The output of DC amplifier U303-c is sent to the selector circuit which generates conditions for Dolby HX system operation. The output of U303-c is fed to the variable bias circuit and variable equalizer circuit only in the following conditions.

NR SYSTEM switch: NR+HX SPEED switch: STANDARD

BIAS switch: Co (CrO₂) or NORMAL

2) Variable bias circuit

The output of the selector circuit is applied to pin 2 of U303-d.

a. U303-d is an inverting amplifier with a gain of 1 using Vcc/2 as its reference voltage. The DC output voltage falls (rises) as the DC input voltage rises (falls).

The output of U303-d controls the base voltage of transistor Q303 which is located in series with the power supply circuit of bias oscillator U103.

- b. When the level of high-frequency components contained in the recording signal is high, the DC voltage applied to pin 2 of U303-d by the control signal circuit rises and, therefore, the DC output voltage from pin 1 of U303-d falls. When the voltage at pin 1 of U303-d falls, the base voltage of Q303 falls and its base current decreases. As a result, the collector current of Q303 decreases, the voltage drop across the collector and emitter increases, and the voltage supplied to bias oscillator U103 falls. When the supply voltage to U103 falls, the output of the oscillator falls, that is, bias is lowered. The minimum and fixed (maximum) bias levels are determined by R328 and R329.
- 3) Variable equalizer

The output of the control signal circuit is supplied to the variable bias circuit and the variable equalizer simultaneously.

- a. The variable equalizer is basically a lowpass filter. A pair of variable conductance amplifiers U302s are used to provide variable cutoff time constant Tc, which is a linear function of the current flowing through resistor R335.
- b. When the level of high-frequency components in the recording signal is high, the DC output voltage of the control signal circuit rises and current flowing through R335 increases. As a result, variable cutoff time constant Tc becomes large and the tumover frequency falls.
- c. Since the variable equalizer is basically a low-pass filter, reduction in turnover frequency results in increased attenuation at high frequencies. Because of this, the recording signal passing through the variable equalizer varies as curves (A) and (B) shown in Fig. 3-37.







Fig. 3-39 Dolby HX system

4. PARTS LOCATION







5. ESSENTIAL MAINTENANCE EQUIPMENT/MATERIAL

Spring scale:

Level meter:

Oscilloscope:

Attenuator:

Cleaner:

Oil:

Band pass filter: Distortion meter:

Test load resistor:

Bulk tape eraser:

Cassette torque meter:

For pinch roller pressure check, 0 to 1 kg (2.2 lbs) For torque check, 0 to 100 g-cm (0 to 1.4 oz-inch),

0 to 160 g-cm (0 to 2.2 oz-inch)

Wow & flutter meter: Audio oscillator:

Frequency counter:

|-|-|-|-

Meguro Dempa Sokki Model MK-668B or equivalent

Hewlett Packard Model 204C or equivalent Range: 0 to 1 MHz, Sensitivity: 0.1 V RMS, Impedance: More than 1 $M\Omega$, less than 25 pF

Range: -80 to +40 dB

Impedance: More than 1 M Ω , less than 25 pF

1 kHz narrow band pass type Basic frequency 400 Hz, 1 kHz

Ordinary type Ordinary type

Noninductive type 8 ohm/1 W

Head demagnetizer: TEAC E-3

TEAC E-2A or equivalent

TEAC recorder cleaner kit or pure alcohol

TEAC oil kit or equivalent

Test tapes: TEAC MTT-111:

TEAC MTT-111: TEAC MTT-150:

TEAC MTT-316:

TEAC MTT-501 or equivalent: TEAC MTT-5061 or equivalent:

TEAC MTT-5072:

Wow & flutter or tape speed test tape, 3000 Hz/- 10 dB Dolby level calibration test tape, Dolby B-type tone

(400 Hz), 200 nWb/m

Head azimuth/frequency characteristic test tape for

EQ Co (CrO₂), 3180 μs +70 μs

Blank test tape for BIAS/EQ NORMAL (normal-bias tape)
Blank test tape for BIAS/EQ Co (CrO₂) (high-bias tape)

Blank test tape for BIAS/EQ METAL

6. ELECTRO-MECHANICAL CHECKS AND ADJUSTMENTS

6-1. HEAD BASE PLATE POSITIONING

- 1) Set the deck in the PLAY mode.
- 2) Push the head base plate by hand in the direction of the arrow and check that the head base plate and the stopper portion of the mechanism chassis make contact.
- 3) If there is any clearance, loosen the two screws on the head base plate solenoid and reposition the solenoid until the clearance is eliminated.




Fig. 6-1




Fig. 6-2 Head base solenoid location

6-2. MICROSWITCH (A) ASSEMBLY CLEARANCE

- 1) Insert a blank cassette and close the cassette holder.
- 2) Loosen the two screws on the microswitch (A).
- 3) Move the switch so that actuator of the switch contacts the safety lever.
- 4) Adjust the switch position to obtain a clearance of between 0.1 mm to 0.3 mm.
- 5) Retighten the screws.




Fig. 6-3

6-3. MICROSWITCH (B) ASSEMBLY CLEARANCE

- 1) Push the EJECT button to open the cassette holder.
- 2) Loosen the two screws on the microswitch (B).
- Move the switch so that switch actuator contacts the bent projecting portion of the eject lever.
- 4) Adjust the switch position to obtain a clearance of approximately 1 mm.
- 5) Retighten the screws.





Fig. 6-4

6-4. CAPSTAN ASSEMBLY THRUST

1) Turn the thrust adjusting screw so that thrust of the capstan shaft is within 0.05 mm to 0.15 mm.



6-5. TAKEUP TORQUE

Takeup torque adjustment is critical to stabilize tape travel and reduce variations in tape speed.

- 1) Load a cassette torque meter (0 to 100 g-cm, 1.4 oz-inch) in the cassette holder.
- 2) Measure the torque by running the tape of the meter in the reproduce mode. The meter reading should be 45 65 g-cm (0.6 0.9 oz-inch).
- 3) If the reading is outside this range, clean the surface of the idler pulley in the reel table assembly which comes into contact with the tape using cleaning liquid. Also check the operation of the moving parts of the reel table assembly.
- 4) If the reading is still unsatisfactory, replace the reel table ass'y.

6-6. FAST FORWARD AND REWIND TORQUE

- 1) Load a cassette torque meter (0 to 160 g-cm, 2.2 oz-inch).
- 2) With the deck in the fast forward and rewind modes, read the meter. If the meter is provided with tape, note the readings with the tape fully wound on the reel taking up the tape in each mode so that the measurement is not influenced by the tape's inertia. The fast forward torque must be in the range 90 160 g-cm (1.3 2.2 oz-inch) and the rewind torque must be in the range 90 160 g-cm (1.3 2.2 oz-inch).
- If the readings are outside these ranges, clean the surface of the idler pulley with cleaning liquid and check the operation of the moving parts of the reel table ass'y.

6-7. PINCH ROLLER PRESSURE

Pinch roller pressure must also be adjusted to the correct value to stabilize tape travel and reduce variation in tape speed.

- 1) Remove the cassette door cover to install the torque scale.
- 2) With the deck in the reproduce mode, attach the scale near the shaft of the pinch roller, being careful not to touch the pinch roller. See Fig. 6-6.
- Move the scale gradually in the direction of the arrow until the capstan shaft and pinch roller are completely separated.
- 4) Gradually return the pinch roller and note the reading on the scale when the pinch roller touches the capstan and starts rotating. The reading should be between 390 and 490 g (13.8 and 17.3 oz).
- 5) If the reading is outside this range, repalce the pinch roller pressure spring or adjust the pressure by bending the spring as shown in Fig. 6-6.




Fig. 6-6

6-8. TAPE SPEED

Use the TEAC MTT-111 test tape (containing highly accurate 3-kHz signals) or its equivalent to measure tape speed.

- 1) Connect a frequency counter to the OUTPUT terminals as shown in Fig. 6-8.
- 2) Play the test tape from the start of the tape and check that the frequency counter reading is within $3 \text{ kHz} \pm 0.5 \%$.
- 3) If the reading is outside this range, clean the tape path and check the pinch roller pressure and takeup tension.
- 4) If these values are correct, adjust the resistor of the motor so that the reading is within the range 3000 Hz ± 5 Hz.

NOTE: Adjust tape speed after the tape has run for about 30 sec in the reproduce mode.




Fig. 6-7

6-9. WOW AND FLUTTER

Before measuring wow and flutter, the following points should be read carefully. It is necessary to decide which of the two measurement methods should be used.

 Reproduce method: Measure while playing wow & flutter test tape MT-111 or its equivalent.

Record/reproduce method: Record a 3-kHz signal on blank tape, rewind the tape and reproduce the recorded signal.

NOTE: When measuring using the record/reproduce method, the recorded section should be reproduced repeatedly to obtain the mean value. Be careful not to read the meter for those parts of the tape in which wow & flutter components in recording and reproducing cancel each other.

- 2) Set the flutter meter controls to the required standard. Select the DIN/IEC/ANSI peak value or the NAB RMS value, then set the weighting control as required.
- 3) Measure at the beginning and the end of the tape. The measured value will differ slightly according to the measuring method and instrument used. Standard values are:

1-7/8 ips: ±0.085 % peak (DIN/IEC/ANSI weighted)

±0.18 % peak (DIN/IEC/ANSI unweighted)

0.06 % (NAB weighted) 0.11 % (NAB unweighted)

3-3/4 ips:

±0.055 % peak (DIN/IEC/ANSI weighted) ±0.13 % peak (DIN/IEC/ANSI unweighted)

0.04 % (NAB weighted) 0.07 % (NAB unweighted)

NOTE: Measure after cleaning the tape path, especially the capstan shaft, pinch roller and head surfaces.






Fig. 6-8







7. RECORD/REPRODUCE AMPLIFIER CHECKS AND ADJUSTMENTS

Remove the top cover by unscrewing the screws securing it. When the top cover is removed, the record/reproduce amplifier PCB ASSY can be seen. When adjusting the azimuth of the record/reproduce head, remove the cassette holder door cover.

The following points should be observed before starting the record/reproduce amplifier checks or adjustments.

- * Before adjusting the amplifier, the erase head, record/reproduce head and tape path should be demagnetized and cleaned with cleaning fluid.
- * Adjust the left channel first, then the right channel. In the circuit diagrams, 100-series numbers refer to left channel components and 200-series numbers refer to right channel components. For example, R180 is a left channel resistor while R280 is the equivalent right channel resistor.

Left channel/Right channel components are shown as R180/R280.

- * $0 \, dB = 1 \, V$
- * Unless otherwise specified, set the switches as follows:

Switches	Positions
MONITOR	TAPE
DOLBY NR	OUT
INPUT	LINE 1 or 2
SPEED	STANDARD
EQ	METAL
BIAS	METAL
MEMORY	OFF
CAL	PRESET

* If characteristics such as frequency response and crosstalk are found to be unsatisfactory, it is necessary to check and adjust the azimuth of the record/reproduce head first prior to performing amplifier adjustment.

Record/reproduce head azimuth check and adjustment

Connect an oscilloscope and a VTVM to the OUTPUT terminals as shown in Fig. 7-1. Play test tape MTT-150 to check that the phase difference between the L and R channels is less than 45°.

Reproduce the 10-kHz/-10 dB signal from test tape MTT-316 and turn the azimuth adjusting nut to maximize the levels of both channels.




Fig. 7-1




Fig. 7-2

7-1. REPRODUCE OUTPUT LEVEL SETTING

- 1) Load test tape MTT-150 and play it.
- 2) Connect the HOT terminal of the VTVM to DOLBY T.P. (TP.1/TP.2) and the COLD terminal of the VTVM to TP (GND) and check that the DOLBY T.P. voltage is 580 mV (-2.5 dB).
- 3) If this value cannot be obtained, adjust semi-fixed resistors R11/R21.
- 4) Also connect the VTVM to the OUTPUT terminal and confirm that the OUTPUT level is -4.5 dBV ±2 dB when the OUTPUT level control is maximum.

7-2. VU METER SETTING

- 1) Load test tape MTT-150 and play it.
- 2) Check that the VU meter reading is ± 3 VU ± 1 VU.
- 3) If the VU meter reading is not correct, adjust semi-fixed resistors R71/R81.

7-3. REPRODUCE FREQUENCY RESPONSE

- 1) Connect a VTVM to the OUTPUT terminal.
- 2) Play test tape MTT-316 and check the output level. Confirm that the level at 10 kHz is within ± 2 dB of the level at 315 Hz.
- 3) If the response is unsatisfactory, adjust semifixed resistors R10/R20. If the result is still unsatisfactory, check the tape travel and head azimuth.
- 4) Play the 10-kHz signal from the test tape and change the EQ switch setting to NORMAL. Confirm that the output level is about 4.5 dB $^{+2}_{1}$ higher than with the switch in the METAL position.

7-4. BIAS SETTING ADJUSTMENT

Before adjusting the bias setting:

- a. Connect the measuring instruments as shown in Fig. 7-3.
- b. Load a blank tape and put the deck in the record/pause mode.
- c. Apply a -14 dBV/400 Hz signal to the LINE 1 or 2 terminal.
- d. Adjust the INPUT (LEFT/RIGHT) level control until the VU meter reads 0 VU.
- e. Adjust the OUTPUT level control so that the OUTPUT terminal level is -10 dBV.




Fig. 7-3

Bias setting at position METAL

- 1) Set the EQ and BIAS switches to METAL
- 2) Alternately record -44 dBV signals at 400 Hz then 10 kHz on blank tape (MTT-5072) and reproduce them.
- NOTE: The level -44 dBV is 30 dB lower than the standard level.
- 3) Note readings of the OUTPUT level at the OUTPUT terminal and check that the output levels are identical for both frequencies.
- 4) If the result is unsatisfactory, adjust semifixed resistors R15/R25.
- NOTE: Turning the semi-fixed resistors clockwise increases bias current and decreases high frequency response; turning them counterclockwise increases high frequency response.

Bias settings at NORMAL and Co (CrO₂) positions

This is done in the same way as for the metal bias setting. Refer to the following table:

Positions	EQ/BIAS switches	Blank tape	Adjusting points
BIAS METAL	METAL	MTT-5072	R15/R25
BIAS Co(CrO2)	Co(CrO ₂)	MTT-5061	R14/R24
BIAS NORMAL	NORMAL	MTT-501	R13/R23

7-5. RECORD LEVEL

Adjust this after the setting of the reproduce and bias levels (7-1 and 7-4) and VU meter (7-2) is complete.

The following items 1) - 5) indicate the standards levels and setting orders of each control.

METAL

- 1) Connect the measuring instruments as shown in Fig. 7-3.
- 2) Set the BIAS and EQ switches to METAL and the MONITOR switch to SOURCE.
- Load blank tape (MTT-5072) and set the deck in the record/pause mode.
- 4) Apply -14 dBV/400 Hz signals to LINE 1 or
- 5) Adjust the INPUT (LEFT/RIGHT) level control until the VU meter reads 0 VU. Adjust the OUTPUT level control so that the OUTPUT terminal level is set to -10 dBV.
- 6) Set the MONITOR switch to TAPE. Record and play the blank tape to check that the OUTPUT level is -10 dBV ±1 dB.
- 7) If satisfactory values are not obtained, adjust semi-fixed resistors R16/R26.

Co(CrO₂) and NORMAL

This is done in the same way for metal tape. Perform adjustment referring to the following table.

Positions	EQ/BIAS switches	Blank tapes	Adjusting points
METAL	METAL	MTT-5072	R16/R26
Co(CrO ₂)	Co(CrO ₂)	MTT-5061	R17/R27
NORMAL	NORMAL	MTT-501	R18/R28

7-6. OVERALL FREQUENCY RESPONSE METAL

Obtain the standard setting according to procedures 1) - 6) of 7-5. and check the record/reproduce signals.

- 1) Obtain -44 dBV by decreasing the input signal level by 30 dB and record and play it on blank tape (MTT-5072).
 - Change the input signal level and confirm that the level at 12 kHz is within ±2 dB of the level at 400 Hz. Also confirm at high tape speed.
 - If the response is unsatisfactory, check whether the record/reproduce head is dirty or set correctly. It is also necessary to check the bias level setting.
- NOTE: Perform this adjustment with the NR SYSTEM switch set OUT.

Co(CrO₂) and NORMAL

Take the same procedures as for metal tape. Refer to Table under paragraph 7-5 for the tapes to be used and the switch settings.

7.7. OVERALL SIGNAL-TO-NOISE RATIO Obtain the standard setting according to proce-

dures 1) — 6) of **7-5**. to check record/reproduce level.

- 1) Recording input signal of -14 dBV/400 Hz on a blank tape for a short time. Then mute the signal and record with no input signal.
- 2) Rewind the tape to the start of the recorded section.
- 3) Play back the recorded section and measure the output level of the section with the signal, then, at the point where the signal stops, increase the sensitivity of the VTVM and measure the output level of the no-signal section. The output level measurement should be weighted.
- 4) Calculate the level ratio of noise with respect to the recorded signal and confirm that they are identical to the values shown in the table below.

For the tapes to be used and the switch settings, refer to Table under paragraph 7-5.

- If the values are unsatisfactory, proceed as follows:
- * Demagnetize and clean the erase and record/ reproduce heads.
- * Check that erasing is being done effectively.
- * Check and adjust reproduce and record/reproduce frequency response.
- * Check and adjust the bias trap.
- * Replace the tape.

SPEED	STANDARD	HIGH
METAL Co(CrO ₂)	More than 48 dB	More than 49 dB
NORMAL	More than 45 dB	More than 46 dB

7-8. OVERALL DISTORTION

- 1) Connect the measuring instruments as shown in Fig. 7-4.
 - Obtain the standard setting according to procedures 2) 6) of 7-5. and check record/reproduce level.
- 2) Record an input signal of -14 dBV/400 Hz on blank tape and play it back to measure the distortion of the output signal.

3) The value should be less than 1.0 % for any of the tapes used.

For the tapes to be used and the switch settings, refer to Table under paragraph 7-5. If satisfactory values are not obtained, check the bias setting again, also check the S/N ratio and the overall frequency response.




Fig. 7-4

7-9. ERASURE

- 1) Connect the measuring instruments as shown in Fig. 7-5. To check that erasing is effective, use a 1-kHz bandpass filter.
- 2) Obtain the standard setting according to procedures 2) 5) of 7-5.
- 3) With a -4 dBV/1 kHz (saturation level) signal, increase the input signal level by 10 dB and record it on blank tape. Reproduce this to measure the OUTPUT terminal level decreasing the sensitivity of the VTVM by about 10 dB.
- 4) Rewind the tape to the start of the recording. Erase the recorded section with no input signal.
- 5) Play back the erased section and measure the output level, increasing the sensitivity of the VTVM.
- 6) Calculate the ratio of the signal output level to the output level obtained by playing the erased tape.
- 7) The value should be more than 65 dB for any of the tapes to be used.

For the tapes to be used and the switch settings, refer to Table under paragraph 7-5. If the erase effect is unsatisfactory, check whether the erase head is clean and the tape is

NOTE: When checking erasure, make sure the blank tape used has been erased by a bulk eraser before using it. Correctly tune the frequency of the signal to be recorded to match the bandpass filter and compensate for measuring instrument loss.

running correctly.




Fig. 7-5

7-10. CHANNEL SEPARATION

- 1) Connect the measuring instruments as shown in Fig. 7-5.
 - For the right channel, connect only the VTVM. For the left channel, install a 1-kHz bandpass filter between the OUTPUT terminal and the VTVM.
- 2) With a 1-kHz input signal, obtain the standard setting according to procedures 2) 6) of 7-5, to check the record/reproduce level.
- 3) Make a stereo recording applying the input signal only to the left channel and no signal to the right channel.
- 4) Rewind the tape to the start of the recording and play it.
 - Measure the output levels of both channels. (The right channel will contain the recorded signal and the left channel will contain components which have leaked from the right channel.).
- 5) Calculate the difference in level between the two channels. This value should be more than 35 dB.

7-11. LED LIGHTING OF VU METER (PEAK indicator)

According to procedures 1) - 5) of **7-5.**, adjust until the VU meter indicates 0 VU.

- 1) Confirm that the LED lights when the input level is increased by 8 dB from -14 dBV and does not light when the input level is increased by 7 dB from -14 dBV.
- 2) If the lighting level is not satisfactory, adjust semi-fixed resistors R72/R82.

7-12. DOLBY NOISE REDUCTION EFFECT

- 1) Connect the measuring instruments as shown in Fig. 7-3.
- Set the EQ and BIAS switches to match the blank tape used and the MONITOR switch to SOURCE.

- 3) Load the blank tape and put the deck in the record/pause mode.
- 4) Apply a -14 dBV/1 kHz signal to the LINE 1 or 2 terminal.
- 5) Adjust the INPUT (LEFT/RIGHT) level control so that the VU meter indicates +3 VU. Also adjust the OUTPUT level control so that the OUTPUT terminal level is -7 dBV.
- 6) Set the MONITOR switch to TAPE. Record a -37 dBV/1 kHz signal on the blank tape, decreasing the input level by 23 dB and reproduce the signal.
- 7) While recording and reproducing, switch the NR SYSTEM switch between NR and OUT to check that the change in level is between 3 and 8 dB.
- 8) Check the level when a -47 dBV/10 kHz signal is recorded and reproduced. The values are shown in the following table.

 Measure the OUTPUT terminal level, increas-


Measure the OUTPUT terminal level, increasing the sensitivity of the VTVM by an amount equivalent to the decrease in the input signal level.

Input signal	Change in Output level
-37 dBV, 1 kHz	between 3 and 8 dB
-47 dBV, 10 kHz	between 8 and 12 dB

7-13. DOLBY HX EFFECT

Follow the same procedures as in 7-12. DOLBY NR EFFECT up to item 3).

- 1) Apply a -14 dBV/400 Hz signal to the LINE 1 or 2 terminal.
- 2) Adjust the INPUT (LEFT/RIGHT) level control so that the VU meter indicates 0 VU. Also adjust the OUTPUT level control so that the OUTPUT terminal level is -10 dBV.
- Set the NR SYSTEM switch to HX and check the response, changing the input signal frequency.



4) If the response decreases at high frequencies, adjust semi-fixed resistor R36 for NORMAL tape and R37 for Co (CrO₂) tape.

7-14. HEADPHONES OUTPUT LEVEL

- 1) Connect an 8-ohm load and a VTVM to the PHONES jack.
- Load test tape MTT-150 and play it back to measure the headphones output level.
- 3) The value should be 0 dBV ± 2 dB (100 mW) when the PHONES knob is set to maximum.

7-15. BIAS TRAP ADJUSTMENT

Bias trap adjustment is only necessary when:

- * the record/reproduce head is replaced,
- * parts in the record amplifier circuit (especially the bias oscillator and trap coil) are replaced,
- * too much bias leakage is observed.
- 1) Set the deck to the record/pause mode.
- 2) Connect the VTVM or oscilloscope's HOT terminal to T.P.3/T.P.4 (junction point between L104/L204 and R176/R276 of the bias trap) and its COLD terminal to TP (GND).
- 3) Adjust L104/L204 so that the level (bias leakage) reading is minimum.
- NOTE: After adjusting the bias trap, check the bias setting, record level and overall frequency response.

7-16. BIAS/REC CALIBRATION CHECK

Prior to this check, set the deck as follows. The tape to be used for calibration is C_0 ($C_{r}O_{2}$) MTT-5061.

- a. Set the EQ and BIAS switches to Co (CrO_2) .
- b. Set the INPUT switch to TEST.
- c. Set the ADJUST/PRESET switch to AD-JUST.
- d. BIAS/REC CALIBRATION: BIAS L/R (R35/R45)

fully counterclockwise REC LEVEL L/R (R30/R40)

fully clockwise

- 1) Set the deck to the RECORD/PAUSE mode and the MONITOR switch to SOURCE.
- 2) Apply a -34 dBV/1 kHz signal to LINE 1, and adjust the INPUT (LEFT/RIGHT) level control so that the VU meter indicates 0 VU. (When observed at the OUTPUT terminal, adjust the OUTPUT level control so that the level is -30 dBV.)

Variable BIAS CAL. range

Record and play back a 1 kHz input signal, setting the MONITOR switch to TAPE.

- 4) While recording and reproducing the signal, turn the BIAS L/R (R35/R45) clockwise to obtain the maximum value (Lmax) of the VU meter. (When observed at the OUTPUT terminal, obtain the maximum level.)
- 5) Also obtain the indication value (L₁) of the VU meter when the BIAS L/R (R35/R45) is turned fully clockwise. (When observed at the OUTPUT terminal, obtain the OUTPUT level at that time.).
- 6) Confirm that the variable range is Lmax $L_1 \ge 4$ VU (or 4 dB at the OUTPUT terminal).


Variable REC CAL. range

- As in the variable BIAS CAL. range, record and reproduce a 1 kHz signal, setting the MONITOR switch to TAPE.
- 8) While recording and reproducing this signal, turn the BIAS L/R (R35/R45) clockwise to obtain the maximum indication value (Lmax) of the VU meter (when observed at the OUTPUT terminal, obtain the maximum level value.).
- 9) Obtain indication value L₂ of the VU meter when REC LEVEL L/R (R30/R40) is turned fully counterclockwise. (Obtain the OUT-PUT level when observed at the OUTPUT terminal.).
- 10) Confirm that the variable range is Lmax L₂ \geq 10 VU (or 10 dB at the OUTPUT terminal).

BIAS/REC CALIBRATION setting

- 1) Set the deck to the RECORD/PAUSE mode and the MONITOR switch to SOURCE.
- 2) Apply a -34 dB/400 Hz signal to LINE 1. Adjust the INPUT (LEFT/RIGHT) level control so that the VU meter indicates 0 VU. (When observed at the OUTPUT terminal, adjust the OUTPUT level control to obtain -30 dBV.)
- 3) Record and reproduce the input signal. Adjust REC LEVEL L/R (R30/R40) to obtain identical VU meter levels (or OUTPUT levels), switching the MONITOR switch between SOURCE and TAPE.
- 4) Record and reproduce the input signal with the MONITOR switch set to TAPE. Adjust BIAS L/R (R35/R45) to obtain the identical VU meter values (or OUTPUT levels), varying the input signal frequency between 400 Hz, 6.3 kHz and 12.5 kHz.
- NOTE: After adjusting BIAS L/R, adjust the RECORD level again. Also check the overall distortion.

8. EXPLODED VIEWS AND PARTS LISTS



Spark Killer,

Spark Killer

*5240172000 Carbon Resistor 39k 5% 1/4W

Pin-Jack, IP

Switch, Power [U, C] Switch, Power [E, UK, A]

0.033 μF + 120Ω/250V [U]

Spark Killer, 0.033 μF + 120Ω/250V [C]

0.0047 µF/250V [E, UK, A]

Bracket, Power Switch

Var. Res., 100kΩ (A)

Var. Res., $250k\Omega$ (B) Var. Res., $50k\Omega$ (B) Knob, Push Switch; K

Bracket, SW PCB

Gear Assy, A

Spring, GND

Chassis, Front

Bracket, Switch 5124022000 Jack, PHONES *5200013700 PCB Assy, SW (MEMORY) [U] *5200013710 PCB Assy, SW (MEMORY)

[All except U] Switch, Rotary; 2-3

Rod, Power Switch

*5200014002 PCB Assy, POWER SUPPLY [U] *5200014012 PCB Assy, POWER SUPPLY

[All except U]

Plate, Insulating

Bracket, B [GE]

PCB Assy, VOLTAGE SELECTOR

Transformer, Power [U, C] Transformer, Power [E, UK, A] Transformer, Power [GE, L]

Transistor, 2SD880Y

Button, B

R Pin, ø5

5282406802 Var, Res 50kA x 2

*5317000300 Plate, Insulating 5231755500 Transistor, 2SD985

*5033295000 Tube, Insulating *5553353100 Bracket, Transformer

[GE, L]

*5534473000 T-Type Rivet *5200031500 PCB Assy, METER AMPL.

Bracket, Var. Res. Gear Assy, Friction

*5555646000 Bracket, Lever Switch

*5555913000 Mask, C *5524082000 Spring, LED: B *5168899000 PCB Assy, LED

*5554653200 Bracket, Meter

5296001900 VU Meter

Switch, Push; 6-2 PCB Assy, SW [U]

*5200013910 PCB Assy, SW [All except U]

Var. Res., $20k\Omega \times 2$ (A)

Spark Killer, 0.01 μF + 300Ω/400V [GE, L]

Switch, Power (GE, L)

REF. NO. PARTS NO. DESCRIPTION

△ 5134018000

△ 5052907000

A 5052911000

△ 5267702500

*5555561000

5330506000

5282406302

5300019500

*5200013900

5282250201 5282250101 5504713000 *5800059300

5504568000

*5504710001

*5504569200

*5524124000

*5800064900

'5800059201

5133019000

5534431000

*5534422100

*5786360500

*5555951001

*5033291000

5231755100

*5555060000

*5168548100

A *5152215000

•5555626000

*5504676000 Foot *5551031200 Chassis, R

*5555912000 Mask, B

5150223000 Var. Res., 1 •5553269101 Chassis, L

2 - 25 🚡 5052906000

5134011000 5134009000

2 - 24

2 - 27 2 - 28

2 - 29 2 - 30 2 - 31

2 - 32 2 - 33

2 - 39 2 - 40 2 - 41

2 - 43

2 - 44 2 - 45

2 - 46

2 . 47

2 - 48

2 - 49

2 - 50

2 - 51 2 - 52

2 - 53 2 - 54 2 - 55

2 - 56 2 - 57

2 - 58 2 - 59

2 - 60

- 62

- 63

- 64 2 - 65

2 - 66 2 - 67

2 - 68 2 - 69

2 - 71 2 - 72

2 - 73 2 - 74

- 38

EXPLODED VIEW-1

REF. NO.	PARTS NO.	DESCRIPTION
1 - 1	5800132000	Cover, Top
1 - 2 1 - 3	*5122168000	Connector, Socket; 6P
1 - 3	*5122165000	Connector, Socket; 3P
1 - 4	*5122166000	Connector, Socket; 4P
1 - 5	•5122172000	Connector, Socket; 10P
1 - 6	*5122167000	Connector, Socket; 5P
1 - 7	*5800059401	Bracket, Handle; L
1 - 8	*5800083400 *5122174000	Escutcheon Assy, Cassette
1 - 9	*5122174000	Connector, Socket; 12P
1 - 10	•5785603025	Spacer
1 - 11	5504712000	Knob Assy, TIMER
1 - 12	*5600038110	Panel Assy, Front
	0000000110	5504711000 Cover Assy, Meter
		5533183002 Knob, Eject
1 - 13	5543027100	Knob, VR
	5534521000	Knob, Lever Switch
1 - 15	*5552340202	Chassis, Rear
	*5502229001	Chassis Assy, Rear
	*5504676000	Foot
1 - 17	*5800059501	Bracket, Handle; R
1 18	*5138009000	Key Unit
1 - 19	*5800133600	Cover Assy, Cassette

EXPLODED VIEW-2

REF	NO.	PARTS NO.	DESCRIPTION
2 -	1	A 5128034000 A 5128075000	Cord, AC Power [GE] Cord, AC Power [U, C]
		A 5128017000	Cord, AC Power [E]
		5128036000	Cord, AC Power [UK]
		<u>A</u> 5350008300	Cord, AC Power [A]
2 ·	2	*5534660000	Strain Relief, AC Power Cord [All except UK]
		*5534661000	Strain Relief, AC Power Cord (UK)
2 .	3	*5534118000	Rivet, Push
2 .	4	*5552381000	Panel, Rear
2 · 2 · 2 · 2 ·	5	*5555063000	Washer, GND
2 .	6	5330505000	Plug, 2P: Shorting
2 .	7	*5800088000	Cover, Shield
2 .	8	*5122225000	Connector, Socket; 6P (BLK)
2 .	Q	*5122282000	Connector, Socket; 4P (RED)
	3	3122282000	Connector, Socket, 4F (NED)
2 -	10	*5122166000	Connector, Socket; 4P (WHT)
2 -	11	*5122167000	Connector, Socket; 5P (WHT)
2 -	12	*5200013400	PCB Assy, IN/OUTPUT [U]
		*5200013410	PCB Assy, IN/OUTPUT
			[All except U]
2 -	13	*5200013300	PC8 Assy, IN/OUTPUT (DBX) [U]
		*5200013310	PCB Assy, IN/OUTPUT (DBX)
			(All except U)
2 -	14	*5200013500	PCB Assy, REMOTE [U]
		*5200013510	PCB Assy, REMOTE [All except U]
2 -	15	*5620013700	Socket Assy, 6P
2 .	16	*558103B000	Clamper, Cord; A
2 .	17	*5122169000	Connector, Socket; 7P (WHT)
2 .	18	*5200013120	PCB Assy, REC-PLAY AMPL [U]
_		*5200013120	PCB Assy, REC-PLAY AMPL
		2200013130	[All except U]
2 .	19	*5122165000	Connector, Socket; 3P (WHT)
2 .	20	*5122284000	Connector, Socket, SP (RED)
2 .	21	*5555565200	Angle, PCB
	22	*5122223000	Connector, Socket; 4P (BLK)
2 .	23	*5122164000	Connector, Socket; 4P (BLK)
2	20	3122104000	Connector, Socket, 2F (VVHI)

[U]: U.S.A. [A]: AUSTRALIA [C]: CANADA [E]: EUROPE


2 - 70 <u>*</u> •5152182100 <u>*</u> •5152184000

[GE]: GENERAL EXPORT (UK): U.K.


Washer, Transformer *5168973200 PCB Assy, FUSE [E, UK, A]

53

EXPLODED VIEW-2



EXPLODED VIEW-3



EXPLODED VIEW-3

REF. NO.	PARTS NO.	DESCRIPTION
3 - 1	*5504673000	Holder Assy, Damper; C
3 - 2	*555555000	Bracket, Damper
3 - 3	5370000600	Motor Assy, Capstan; DC
3 - 4	*5800064601	Plate, Flywheel Base
3 - 5	•5534277000	Bearing, Flywheel
3 - 6	*5200014101	PCB Assy, JOINT [U]
	*5200014111	PCB Assy, JOINT [All except U
3 - 7	5504757000	Flywheel Assy, Capstan
3 - 8	5163040000	Solenoid, B
3 - 9	5163039100	Solenoid, A
3 - 10	5313000500	Salenoid
3 - 11	•5555546000	Arm, Pressure; B
3 - 11	*5581038000	Clamper, Cord, A
3 - 12	*5800062600	
3 - 13	*5524195000	Lever, Actuating Spring, Lever
3 - 15	*5504666000	Lever Assy, Pause Actuating
3 - 16	*5534611000	Arm, Pause Actuating
3 - 17	*5800061900	Arm Assy, Actuating
3 - 18	*5504665000	Lever Assy, Actuating
3 - 19	*5524213000	Spring, Actuating; A
3 - 20	*5800065500	Bracket Assy, Solenoid; B
3 - 21	*5555543000	Bracket, Switch
3 - 22	5130003000	Switch, Micro
3 - 23	*5534610000	Arm, Base Actuating
3 - 24	*5800062700	Spring, Pulley Guide
3 - 25	*5800062900	Plate, Pulley Guide
3 - 25 3 - 26	*5504667000	Lever Assy, Pause
2 27		
3 - 27 3 - 28	*5524203000	Spring, Damper String, Damper
3 - 28	*5788202100 *5555556000	Angle, Spring
		ACCURATION AND ADDRESS OF THE PARTY OF THE P
3 - 30	*5800060100	Chassis Assy, Mechanism
3 - 31 3 - 32	*5800062300	Bracket, Switch
3 - 32	*5800062800	Spring, Cassette Pressure
3 - 33	*5800061600	Arm, Cassette Pressure
3 - 34	*5504670000	Lever Assy, Eject
3 - 35	*5524199000	Spring, Eject
3 - 36	*5800063000	Guide, Actuating Bar
3 - 37	*5800062500	Bar, Brake Actuating
3 - 38	*5534130000	Washer, Oil Retaining
3 - 39	5504091000	Housing Assy, Capstan
3 - 40	•5550031000	Washer Thrust
3 - 41	5504808000	Pulley Assy, Fast Wind
3 - 42	*5524274000	Spring, Arm
3 - 43	5800063100	Belt, Capstan Drive
3 - 44	5800062400	Pulley, Motor
3 - 45	*5504807001	Plate Assy, Motor
3 - 46	7105135000	Motor Assy, Reel; DC
3 - 46 3 - 47	•5534537000	Collar, Rubber
3 - 48	*5800102100	Angle, Base
3 - 40	2000102100	Aligie, base

EXPLODED VIEW-4

	PARTS NO.	DESCRIPTION
4 - 1	*5553285001	Holder, Cassette
4 - 2	*5544958000	Shaft, Lock Plate
4 - 3	*5534612000	Plate, Lock
4 - 4	*5534613000	Guide, Cassette; L
4 - 5	*5555655000	Plate, Cassette Holder
4 - 6	*5534615000	Spring, Cassette Pressure
4 - 7	*5555582000	Tape, Adhesive
4 - 8	*5534638000	Lens, Lamp
4 - 9	*5534844000	Shoe, Brake
4 - 10	*5520333000	Spring, Brake
4 - 11	•5504669002	Plate Assy, Brake; B
4 - 12	•5210010200	PCB, LAMP [U]
	*5210022400	PCB, LAMP [All except U]
4 - 13	*5142026000	Lamp, DC 6V 65mA
4 - 14	*5544656000	Lamp, DC 6V 65mA Shaft, Lever
4 - 15	*5555544000	Lever, Record Preventing; D
4 - 16	*5524197000	Spring, Lever
4 - 17	*5555535000	Bracket, Counter Assy
4 - 18	5504660001	Counter Assy
4 - 19	5534617000	Belt, Counter
4 20	*EE 24440000	Mounting Bubba
4 - 20	*5534448000 *5200018410	Mounting Rubber PCB Assy, REED SW [All except U
4 - 21	5200018410	
	*5200019400	5138006000 Reed Switch
4 - 22	*5200018400	PCB Assy, REED SW [U]
4 - 22	*5534444200	Guide, Cassette
4 . 23	*5524201000	Spring, Eject Arm
4 - 24	*5555551000	Arm, Eject
4 - 25	*5800090600	Holder Assy, Switch
4 - 26	*5800098500	Cushion, Reel
4 - 27	*5555552000	Arm, Eject Actuating
4 - 28	5800063800	Pulley Assy, Reel; R
4 - 29	*5581055000	Screw, Shoulder
4 - 30	5800063700	Pulley Assy, Reel; L
4 - 31	*5555549000	Arm, Eject Preventing
	*5524200000	
4 - 32 4 - 33	*5534606000	Spring, Arm Arm, Pinch Roller
	5504000001	
	5504828001	Arm Assy, Pinch Roller
	*5800060100	Chassis Assy, Mechanism
4 - 36	*5524285000	Spring, Pinch Roller
4 - 37	*5555531000	Plate, Head Base; B
4 - 38	*5555530000	Plate, Head Base; A
4 . 39	*5504717000	Plate Assy, Head Base
4 - 40	*5581062000	Clamper, Cord; E
4 - 41	5540055000	Steel Ball, 62
4 - 42	*5555533000	Plate, Pressure
4 - 43	*5800064400	Spacer, Erase Head
4 - 44	5569613000	Head, Erase
4 - 45	*5524141000	Spring Height Adi
4 - 46	*5524208000	Spring Tension
4 - 45	*5533174000	Spring, Tension Arm, Tension
4 - 48	5540056000	Steel Ball, 63
4 - 48	3540056000	Steel Dall, ØS
4 - 49	5800063300	Table Assy, Reel; R
4 - 50	5800063200	Table Assy, Reel; L
4 - 51	5534683100	Guide, Cassette; L
4 - 52	*5504716000	Plate Assy, Head Mounting
4 - 53	•5555658000	Plate, Tension Adj.
4 - 54	5569606100	Head, REC-PLAY
4 - 55	5534614000	Guide, Cassette; R
	*5504714000	Bracket Assy, Holder; L
4 - 56	5504/14000	
4 - 56 4 - 57 4 - 58	*5504715000	Bracket Assy, Holder; R


[U]: U.S.A. [A]: AUSTRALIA [L]: LIMITED AREA

[C]: CANADA


9. PC BOARDS AND PARTS LISTS

PC Boards shown viewed from foil side.


LEVER SWITCH PCB ASSY



EXPLODED VIEW-4



REC/PLAY AMPL PCB ASSY




- NOTES

 1. PC Boards shown viewed from foil side.
 2. The colors used on the PCB illustrations have the following significance:
 : +B power supply circuit
 : -B power supply circuit
 : GND
 : Other


 2. Resistor values are in ohms (k = 1,000 ohms).

 - Resistor values are in ohms (k = 1,000 ohms).
 All capacitor values are in microfarads (ρ = picofarads).


JOINT PCB ASSY



POWER SUPPLY PCB ASSY



METER AMPL PCB ASSY



LEVER SWITCH PCB ASSY

REF. NO.	PARTS NO.	DESCRIPTION	REF
1 1	5200013900 5200013910	PCB Assy [U] PC8 Assy [All except U]	R358 R358 R360
	5210013900 5210022000	PCB [U] PCB [All except U]	R36:
	IC's		R363
U301,U401 U302 U303	514 7040000 5220405200 5220405300	NE6458 LM13600 LM324	C301
	TRANSISTO	ORS	C303
	5145178000	2SC1684S	C305
Q302, Q402 Q303	5145178000 5231755500	2SC1684S 2SD985	C306
	DIODES		C308
D301	5143198000	Zener, EQA01-13R 1S2473HJ	C310
D302~D304 D305	5143118000	Zener, EQA01-06S	C311
All resist		N RESISTORS ±5% tolerance and 1/4 watt.	C312 C313 C314 C315
R301, R401	5183101000	6.2kΩ 6.2kΩ	C316
R303, R403	5183101000 5183086000 5183098000	1.5kΩ	C317
R304, R404 R305, R405	5183098000	4.7kΩ 220Ω	C319
R306 R307	5183066000 5183086000	220Ω 1.5kΩ	C321
R309, R409	5183082000	1kΩ	C322
R310, R410 R311, R411	5183058000 5183118000	100Ω 33kΩ	C323 C324 C325
	5183058000	100Ω	C326
R313, R413 R314, R414	5183118000 5183118000	33kΩ 33kΩ	C330
R315, R415 R316, R416	5183042000 5183094000	22Ω 3.3kΩ	C332
R317, R417	5183122000		C334
R318, R418 R319	5173136000 5183122000	200kΩ 47kΩ	C335
R320, R420 R321	5183140000 5183130000	270kΩ 100kΩ	
R322	5183152000	820kΩ	R36.
R323	5183114000	22kΩ	1130
R324, R325 R326, R327	5183106000 5183130000	10kΩ 100kΩ	
R328	5183082000	1kΩ	L301
R329 R330	5183084000 5183098000		
R331	5183138000	220kΩ	S1
R332, R432 R333, R433	5183066000 5183106000	220Ω 10kΩ	S2 S3
R334 R335	5183138000	220kΩ 15kΩ	S4 S5
R335 R336, R436	5183110000 5183090000	2.2kΩ	S6
R337, R437 R338, R438	5183106000 5183150000	10kΩ 680kΩ	
R340	5183098000	4.7kΩ	U305
R341 R355, R455	5183130000 5183060000	100kΩ 120Ω	
R356, R456	5183050000	47Ω	1 1

	PARTS NO.	DESCR	IPTION		
R358, R458 R359, R459 R360, R460 R361, R461 R362, R462	5183120000 5183128000 5183104000 5183128000 5183098000	39kΩ 82kΩ 8.2kΩ 82kΩ 4.7kΩ			
R363, R463	5183070000	330Ω			
	CAPACITO	RS			
C301 C302 C303, C403 C304 C404 C305, C405	5173054800 5173071800 5173733000 5173553800 5173735000	Elec. Elec. Polypro. Elec. Polypro.	0.33µF	16V 10V 100V 50V 100V	5% 5%
C306, C406 C307, C407	5172324000 5173561800	Ceramic Elec.	0.001μF 3.3μF	50V 25V	10%
C308, C408 C309, C409	5172324000 5173561800	Ceramic Elec.	0.001μF 3.3μF	50 V 25 V	10%
C310, C410 C311 C411 C312 C412	5170419000 5170435000	Mylar Mylar	0.0056μF 0.027μF	100V	5%
C312 C412 C313 C413 C314 C414	5170417000 5173010800 5173010800	Mylar Elec. Elec.	0.0047µF 10µF 10µF	100V 16V 16V	5%
C315 C415	5170441000		0.047µF		5%
C316, C416 C317, C417 C318 C319 C320, C420	5170449000 5260225812 5172316000 5173010800 5172996800	Mylar Elec. Ceramic Elec. Elec.	0.1µF 0.33µF 220pF 10µF 2.2µF	100V 50V 50V 16V 50V	5% 10% 10%
C321 C322, C422 C323, C423 C324, C424 C325	5170425000 5054330000 5173734000 5173010800 5173046800	Dip. Mica	0.01μF 150pF 0.0015μF 10μF 100μF	100 V 50 V 100 V 16 V 25 V	5% 10% 5%
C326 C330, C430 C331, C431 C332, C432 C333, C433	51 7231 2000 51 70421000 51 70427000 51 70427000 51 70423000	Ceramic Mylar Mylar Mylar Mylar	100pF 0.0068µF 0.012µF 0.012µF 0.0082µF	50 V 100 V 100 V 100 V 100 V	10% 5% 5% 5% 5%
C334, C434 C335, C435 C336, C436	5170429000 5170419000 5170421000	Mylar Mylar Mylar	0.015µF 0.0056µF 0.0068µF	100V 100V 100V	5% 5% 5%
	VARIABLE	RESISTO	ORS		
R36, R37	5280004002	Semi-fixe	d 50kΩ(8	3)	
	COILS				
L301, L401	5286000400	Chake, 8	mH; Variabl	е	
	SWITCHES				
\$1 \$2 \$3 \$4 \$5 \$6	5300510200 5300510700 5300510600 5300511500 5300511600 5300510600	Lever, 2-2 Lever, 6-3 Lever, 4-3 Lever, 10 Lever, 4-3	3 3 -2 -3		
	MISCELLA	NEOUS			
	5292802600	Filter, Lo	w-pass		

[U]: U.S.A. [A]: AUSTRALIA [L]: LIMITED AREA

[C): CANADA [E]: EUROPE

REC/PLAY AMPL PCB ASSY

REF. NO.	PARTS NO.	DESCRIPTION
AEF. NO.		
1	5200013211 5200013131	PCB Assy [U] PCB Assy [All except U]
l.	5210013100 5210021 <i>2</i> 00	
}	IC's	
U101, U201 U104 U601	5147040000 5147024000 5147047000	JRC4558DF
	TRANSISTO	DRS
Q102, Q202	5145119000 5042461000 5145185000 5145086000 5145132000	
Q111 Q112 Q113 Q114 Q115	5145178000 5145132000 5145178000 5145082000 5145178000	2SA933LNS 2SC1684S 2SC2060Q
Q116, Q216 Q117, Q217 Q118, Q218 Q601, Q602 Q603, Q604	5145185000 5145178000 5145132000 5230770700 5145091000	2SD655E 2SC1684S 2SA933LNS 2SC1841E 2SC945AK
Q605 Q606~Q609 Q610 Q611~Q614	5042553000	2SC945AK 2SA733P
1	DIODES	
D101, D201 D601 ~ D604 D605 D606 ~ D608 D609	5224012510 5143143000	Zener, EQA01-13RF 1S2076 Zener, RD4.3E 1S2076 Zener, RD4.3E
D610, D611	5224012510	1S2076
All resist		I RESISTORS 5% tolerance and 1/4 watt.
R101, R201 R102, R202 R103, R203 R104, R204 R105, R205	5183126000 5183122000 5183034000 5183058000 5183118000	68kΩ 47kΩ 10Ω 100Ω 33kΩ
R106, R206 R107, R207 R108, R208 R109, R209 R110, R210	5183098000 5183140000 5183072000 5183098000 5183082000	4.7kΩ 270kΩ 390Ω 4.7kΩ 1kΩ
R111, R211 R112, R212 R113, R213 R114, R214 R115, R215	5183104000 5183114000 5183130000 5183094000 5183094000	8.2kΩ 22kΩ 100kΩ 3.3kΩ 3.3kΩ
R116, R216 R117, R217 R118, R218 R119, R219 R120, R220	5183064000 5183064000 5183082000 5183118000 5183058000	180Ω 180Ω 1kΩ 33kΩ 100Ω

	=== 110		
	REF. NO.	PARTS NO.	DESCRIPTION
	R121, R221	5183118000	33kΩ
	R122, R222 R123, R223	5183042000 5183094000	22 Ω 3.3k Ω
	R124, R224	5183122000	47kΩ
	R125, R225	5183137000	200kΩ
	R126, R226	5183140000	270kΩ
	R127, R227	5183066000	220Ω
	R128, R228 R147	5183082000 5183106000	1kΩ 10kΩ
	R148~R151	5183130000	100kΩ
	R152	5183128000	9340
	R152	5183128000	82k Ω 4.7k Ω
	R154	5183114000	22kΩ
	R155 R156	5183130000 5183110000	100kΩ
	H130	5163110000	15kΩ
1	R157	5183106000	10kΩ
1	R158 R159	5183098000 5183114000	4.7kΩ 22kΩ
	R160	5183010000	1Ω
	R161	5183086000	1.5kΩ
	R162	5183110000	15kΩ
1	R163, R263	5183126000	68kΩ
	R164, R264 R165, R265	5183118000 5183122000	33kΩ 47kΩ
	R166, R266	5183122000	10kΩ
1			
1	R167, R267 R168, R268	5183138000 5183104000	220kΩ 8.2kΩ
1	R169, R269	5183130000	100kΩ
	R170, R270	5183058000	100Ω
	R171, R271	5183094000	3.3kΩ
	R172, R272	5183122000	47kΩ
1	R173, R273 R174, R274	5183118000 5183090000	33kΩ 2.2kΩ
	R175, R275	5183118000	33kΩ
	R176, R276	5183096000	3.9kΩ
1	R177, R277	5183122000	47 kΩ
	R178, R278	5183122000	47kΩ
١	R179, R279 R180, R280	5183114000 5183098000	22kΩ 4.7kΩ
1	R181, R281	5183108000	12kΩ
١	D400 D400	E102106000	101.0
1	R182, R183 R184, R284	5183106000 5183096000	10kΩ 3.9kΩ
1	R185, R285	5183114000	22kΩ
Į	R186, R286	5183128000 5183106000	82kΩ 10kΩ
١	R187, R287	3183100000	10132
1	R188	5183084000	1.2kΩ 10kΩ
1	R189, R289 R190, R290	5183106000 5183114000	22kΩ
1	R191, R291	5183106000	10kΩ
ł	R192, R292	5183106000	10kΩ
J	R193, R293	5183108000	12kΩ
1	R194, R294	5183106000 5183108000	10kΩ 12kΩ
ł	R195, R295 R196, R296	5183134000	150kΩ
J	R197	5183098000	4.7kΩ
	R601~R607	5183046000	33Ω
	R608	5183118000	33kΩ
	R609 R610	5183026000 5183110000	4.7Ω 15k Ω
	R611	5183118000	33kΩ
			*
			· ·

[U]: U.S.A. [A]: AUSTRALIA [L]: LIMITED AREA

[C]: CANADA [E]: EUROPE

REF. NO.	PARTS NO.	DESCRIPTION		
R612~R614 R616, R617 R618, R619 R620 R621	5183112000 5183110000 5183106000 5183112000 5183074000	18kΩ 15kΩ 10kΩ 18kΩ 470Ω		
R622, R623 R624 R626 R627 R628	5183112000 5183110000 5183086000 5183106000 5183074000	18kΩ 15kΩ 1.5kΩ 10kΩ 470Ω		
R629 R630, R631 R632 R633, R634 R639	5183110000 5183062000 5183110000 5183086000 5183118000	15kΩ 150Ω 15kΩ 1.5kΩ 33kΩ		
R640 R641 R642 R643 R644	5183062000 5183100000 5183092000 5183116000 5183062000	150Ω $5.6\mathrm{k}\Omega$ $2.7\mathrm{k}\Omega$ $27\mathrm{k}\Omega$ 150Ω		
R645 R646 R647 R648~R650 R651	5183116000 5183100000 5183078000 5183104000 5183086000	27kΩ 5.6kΩ 680Ω 8.2kΩ 1.5kΩ		
R652 R653, R654 R655 R656, R657 R658	5183074000 5183106000 5183086000 5183110000 5183086000	470Ω 10kΩ 1.5kΩ 15kΩ 1.5kΩ		
R659 R660 R661 R662	5183110000 5183112000 5183100000 5183046000	15kΩ 18kΩ 5.6kΩ 33Ω		
	CAPACITO	RS		
C101, C201 C102, C202 C103, C203 C104, C204 C105, C205		Elec. 47µF Dip. Tant. 15µF Elec. 47µF Mylar 0.01µF Ceramic 22pF	100V	5% 10%
C106, C206 C107, C207 C108, C208 C109, C209 C110, C210	5173552800 5170409000 5170401000 5173054800 5173053800	Elec. 0.22µF Mylar 0.0022µF Mylar 0.001µF Elec. 220µF Elec. 220µF	50V 100V 100V 16V 16V	5% 5%
C111, C211 C112, C212 C113, C213 C114, C214 C115, C215	5173552800 5170407000 5054745000 5172324000 5173561800	Elec. 0.22 µF Mylar 0.0018 µF Dip, Mica 220 pF Ceramic 0.001 µF Elec. 3.3 µF	50V 100V 50V 50V 25V	10% 10%
C116, C216 C117, C217 C118, C218 C119, C219 C120, C220	5172324000 5170419000 5170435000 5170417000 5173010800	$\begin{array}{ccc} \text{Ceramic} & 0.001\mu\text{F} \\ \text{Mylar} & 0.0056\mu\text{F} \\ \text{Mylar} & 0.027\mu\text{F} \\ \text{Mylar} & 0.0047\mu\text{F} \\ \text{Elec.} & 10\mu\text{F} \end{array}$	50V 100V 100V 100V 16V	10% 5% 5% 5%
C121, C221 C122, C222 C123, C223 C124, C224	5173010800 5170441000 5170449000 5260225812	Elec. 10μF Mylar 0.047μF Mylar 0.1μF Elec. 0.33μF	16V 100V 100V 50V	5% 5% 10%

REF. NO.	PARTS NO.	DESCRIP	PTION		
C135	5173507800	Elec.	47µF	6.3V	
C136	5173563800	Elec.	3.3µF	50V	
C137	5173554800 5173560800	Elec.	0.47μF 2.2μF		
C138 C139, C239	5173560800	Mylar	2.2μF 0.18μF		5%
C140, C240	5173729000	Polypro.	560pF	100V	5%
C141, C241	5173554800	Elec.	0.47µF	50V	0 /0
C142, C242	5173052800	Elec.	220µF	6.3V	
C143, C243	5173481800	Elec.	3.3µF	25V	
C144, C244	5173731000	Polypro.	820pF	100V	5%
C145, C245	5173728000	Polypro.	470pF		5%
C146, C246 C147	5173010800 5173010800	Elec.	10μF 10μF	16V 16V	
C147, C248	5173734000	Polypro.		100V	5%
C149, C249	5173010800	Elec.	10μF	16V	3 /0
C150, C250	5173010800	Elec.	10µF	16V	
C151, C251	5170411000	Mylar	0.0027µF		5%
C152	5173550800	Elec.	0.1µF	50V	
C153	5172344000	Ceramic	0.047µF	50V	10%
C154, C254	5173010800	Elec.	10μF	16V	
C160	5172336000	Ceramic	0.01µF	50V	
C601 ~ C605 C606	5172336000 5173010800	Ceramic Elec.	0.01μF 10μF	50V 16V	10%
C607	5172336000	Ceramic	0.01µF	50V	10%
C608	5054230000	Ceramic	0.047µF	50V	10%
C609	5173027800	Elec.	33µF	16V	
C610	5173053800	Elec.	220µF	10V	
C611	5172992800	Elec.	1μF	50V	
C612	5173035800	Elec.	47µF	10V	
	THERMIST	ORS			
RT10, RT20 RT11, RT21	5143127000 5143127000	S5 C14 S5 C14			
in in in it	VARIABLE		ORS		
D10 D00				(D)	
R10, R20 R11, R21	5280004002 5280004002	Semi-fixe Semi-fixe		Total Land	
R13, R23	5280004002	Semi-fixe			
R14, R24	5280004302	Semi-fixe			
R15, R25	5280004202	Semi-fixe			
R16, R26	5280004002	Semi-fixe	ed 50kΩ	(B)	
R17, R27	5280004002	Semi-fixe		100	
R18, R28	5280004002	Semi-fixe	d 50kΩ	(B)	
	COILS				
L101, L201	5160107000	Choke, 1			
L102, L202	5286001100	Choke, 3	8mH		
L103, L203 L104, L204	5286001200 5286001000	Trap, 12r	nH .1mH; Varia	ble	
L105	5160151000	Choke, 1		DIG	
	MISCELLA	NEOUS		*	
U103	5292200300		, 100kHz		
P1	5122126000	Connecto	r Plug, 2P (
P2	5122130000	Connecto	or Plug, 6P (WHT)	
P3 P4	5122127000 5122128000	Connecto	or Plug, 3P (WHT)	
P5	5122301000		or Plug, 4P (
P6	5122301000		or Plug, 4P (
P7	5122187000		r Plug, 6P (
P8	5122130000	Connecto	r Plug, 6P (WHT)	
P9	5122185000	Connecto	or Plug, 4P (BLK)	
P10	5122127000		r Plug, 3P (
P11	5122131000	Connecto	or Plug, 7P (WHT)	

[U]: U.S.A. [A]: AUSTRALIA [L]: LIMITED AREA

[C]: CANADA [E]: EUROPE

JOINT PCB ASSY

REF. NO.	PARTS NO.	DESCRIPTION		
		PCB Assy [U] PCB Assy [All except U]		
, l	5210014100 5210022300	PCB [U] PCB [All except U]		
	TRANSISTO	OR .		
Q692	5231756800	2SD826EFG		
ĺ	DIODES			
D693~D695	5224013210	DS135D		
	CARBON R	RESISTORS		
R693 R694		560Ω 5% ¼W 15Ω 5% ¼W		
	CAPACITOR	RS		
C691, C692	5173010800 5172324000	Elec. 10μF 16V Ceramic 0.001μF 50V 10%		
	MISCELLA	NEOUS		
P692		Connector Plug, 10P (WHT) Connector Plug, 5P (WHT) Connector Plug, 4P (WHT)		

POWER SUPPLY PCB ASSY

REF. NO.	PARTS NO.	DESCRIPTION
		PCB Assy (C) PCB Assy (All except C)
	5210014001 5210022101	PCB (C) PCB (All except C)
}	TRANSISTO	DRS
Q501, Q502 Q503, Q504 Q505 Q506 Q507	5231755500 5145085000 5231755100 5145091000 5231755500	2SA934R 2SD880Y 2SC945AK
Q508 Q509, Q510 Q511 Q512, Q513 Q514, Q515	5042553000 5230505300 5230770700 5231755500 5230505300	2SA733P 2SB750 2SC1841E 2SD985 2SB750
Q518	5231755100 5230505300 5145091000	2SD880Y 2SB750 2SC945AK
	DIODES	
D501, D502 D503 D504, D505 D506 D507~D511	5224012510 5224013210 5224012510 5224013210 5224012510	1S2076 DS135D 1S2076 DS135D 1S2076
D515~D517	5143059000 5224012510 5224013210 5143153000 5224012510	1S2076 DS135D Zener, EQA01-06R
	5224013210 5224013210	

REF. NO.	PARTS NO.	DESCRIPTION
All resist		RESISTORS 5% tolerance and 1/4 watt.
R501	5183112000	18kΩ
R502	5183086000	1.5kΩ
R503	5183094000	3.3kΩ
R504	5183142000	330kΩ
R505	5183100000	5.6kΩ
R506	5183142000	330kΩ
R507	5183094000	3,3kΩ
R508	5183112000	18kΩ
R509	5183076000	560Ω
R510	5183074000	470Ω
R511	5183110000	15kΩ
R512	5183106000	10kΩ
R513	5183098000	4.7kΩ
R514	5183098000	1.5kΩ
R515	5183090000	2.2kΩ
R518 R519 R520, R521	5183110000 5183114000 5183086000 5183106000 5183096000	15kΩ 22kΩ 1.5kΩ 10kΩ 3.9kΩ
R524	5183106000	10kΩ
R525	5183110000	15kΩ
R526	5183102000	6.8kΩ
R527	5183092000	2.7kΩ
R528	5183110000	15kΩ
R529	5183086000	1.5kΩ [°]
R530	5183090000	2.2kΩ
R531	5183110000	15kΩ
R532~R533	51831106000	10kΩ
R534	5183110000	15kΩ
R535	5183096000	3.9kΩ
R536	5183106000	10kΩ
R537	5183110000	15kΩ
R538	5183096000	3.9kΩ
R539	5183106000	10kΩ
R540	5183090000	2.2kΩ
R541, R542	5183098000	4.7kΩ
R543	5183090000	2.2kΩ
R544	5183102000	6.8kΩ
R545	5183110000	15kΩ
R546 R547 R548, R549 R550 R551	5184233000 5183102000 5183130000 5183104000 5183106000	22Ω , Non Flammable $6.8 k\Omega$ $100 k\Omega$ $8.2 k\Omega$ $10 k\Omega$
R552	5183066000	220Ω
R553	5183136000	$180\mathrm{k}\Omega$
R554	5183106000	$10\mathrm{k}\Omega$
R555	5183112000	$18\mathrm{k}\Omega$
R556	5184225000	10Ω , Non Flammable
R557	5183110000	15kΩ
R559	5183310000	5.6kΩ
	CAPACITO	RS
C501, C502 C503 C504 C505 C506	5054230000 5173072800 5173053800 5173045800 5173082800	Ceramic 0.047μF 50V 10% Elec. 470μF 16V Elec. 220μF 10V Elec. 100μF 16V Elec. 1000μF 25V
C507 C508 C509 C510 C511	5173010800 5173006800 5173044800 5173035800 5173072800	Elec. 10µF 16V Elec. 4.7µF 50V Elec. 100µF 10V Elec. 47µF 10V Elec. 470µF 16V

[U]: U.S.A. [A]: AUSTRALIA [L]: LIMITED AREA

[C]: CANADA [E]: EUROPE

REF. NO.	PARTS NO.	DESCR	RIPTION	
C512	5173036800	Elec.	47µF	16V
C513	5173084800	Elec.	1000µF	50 V
C514	5173082800	Elec.	1000µF	25V
C515	5173013800	Elec.	10µF	50V
C516	5173006800	Elec.	4.7µF	50V
C517	5173073800	Elec.	470µF	25V
C518	5173048800	Elec.	100µF	50V
C519	5172992800	Elec.	1µF	50V
C520	5173084800	Elec.	1000µF	50V
C521	5173588800	Elec.	47µF	10V
C522	5172992800	Elec.	1µF	50V
C523	5173053800	Elec.	220µF	10V
C524	5173071800	Elec.	470µF	10V
C525	5173044800	Elec.	100µF	10V
C526	5173028800	Elec.	33µF	25V

METER	AMPI	PCR	ACCV
MEIEN	AIVIPL	PUB	A331

REF. NO.	PARTS NO.	DESCRIPTION
	5200031500 5210031500	PCB Assy PCB
	IC's	
U701 U702	5147056000 5220406800	HD-7400P Analog, TA7230P
	TRANSIST	ORS
Q701, Q801 Q702, Q802 Q703, Q803 Q704, Q804	5145178000 5145178000 5145178000 5145178000	2SC-1684S 2SC-1684S 2SC-1684S 2SC-1684S
	DIODES	
D701, D801 D702, D802 D703, D803	5224012800 5224012800 5143118000	0A90R 0A90R 1S2473HJ
	CARBON R	ESISTORS
All resist	tors are rated :	±5% tolerance and 1/4 watt.
R701, R801 R702, R802 R703, R803 R704, R804 R705, R805	5183122000 5183088000 5183152000 5183122000 5183098000	47kΩ 1.8kΩ 820kΩ 47kΩ 4.7kΩ
R706, R806 R707, R807 R708, R808 R709, R809 R710, R810	5183062000 5183098000 5183142000 5183114000 5183091000	150Ω 4.7kΩ 330kΩ 22kΩ 3.9kΩ
		17 17 17 17 17 17 17 17 17 17 17 17 17 1
R711, R811 R712, R812 R713, R813 R714, R814 R715, R815	5183564000 5183074000 5183090000 5183098000 5183082000	100Ω 470Ω 2.2kΩ 47kΩ 1kΩ
R712, R812 R713, R813 R714, R814	5183074000 5183090000 5183098000	470Ω 2.2kΩ 47kΩ

REF. NO.	PARTS NO.	DESCRI	PTION		
	CAPACITO	RS			
C701, C801	5172992800	Elec.	1μF	50V	
C702, C802	5173011800	Elec.	10µF	25V	
C703, C803	5173005800	Elec.	4.7µF	35V	
C704, C804	5172992800	Elec.	1µF	50 V	
C705, C805	5172992800	Elec.	1µF	50V	
C706, C806	5172992800	Elec.	1µF	50V	
C707	5173011800	Elec.	10µF		
C708, C808	5173005800	Elec.	4.7µF		
C710	5173018800	Elec.	22µF	16V	
C711, C811	5173036800	Elec.	47µF	16V	
C712, C812	5170449000	Mylar	0.1µF	100V	±5%
C713, C813	5173071800	Elec.	470µF		
C714	5173081800	Elec.	1000µF		
	VARIABLE	RESISTO	RS		
R71, R81	5150156000	Semi-fixed	50kΩ(E	3)	
R72, R82	5150154000	Semi-fixed	10kΩ(E	3)	

IN/OUTPUT TERMINAL PCB ASSY (DBX) (PC Board Omitted)

REF. NO.	PARTS NO.	. DESCRIPTION	
	5200013300	PCB Assy [U]	
	5200013310	PCB Assy [All except U]	
	5210013300	PCB [U]	
	5210021400	PCB [All except U]	
R365, R465	5183118000	Resistor, Carbon 33kΩ 5% ¼W	

IN/OUTPUT TERMINAL PCB ASSY (PC Board Omitted)

REF. NO.	PARTS NO.	DESCRIPTION
CONTRACTOR OF	5200013400	PCB Assy [U]
	5200013410	PCB Assy [All except U]
	5210013400	PCB [U]
	5210021500	PCB [All except U]
R379, R479	5183120000	Resistor, Carbon 39kΩ 5% ¼W
P13	5122129000	Connector Plug, 5P (WHT)

SWITCH PCB ASSY (MEMORY) (PC Board Omitted)

REF. NO.	PARTS NO.	DESCRIPTION					
	5200013700 5200013710	PCB Assy (Memory) [U] PCB Assy (Memory) [All except U]					
	5210013700 5210021800						
Q691 R691 R692 S691	5145091000 5183086000 5183076000 5133019000		w w				

[A]: O.S.A. [A]: AUSTRALIA [L]: LIMITED ARE [C]: CANADA [E]: EUROPE

REMOTE CONNECTOR PCB ASSY (PC Board Omitted)

REF. NO.	PARTS NO.	DESCRIPTION		
		PCB Assy [U] PCB Assy [All except U]		
		PCB [U] PCB [All except U]		
	5122336000	Connector Socket, 12P		

REED SWITCH PCB ASSY (PC Board Omitted)

REF. NO.	PARTS NO.	DESCRIPTION
5200018400 5200018410		PCB Assy [U] PCB Assy [All except U]
	5210018400 5210022500	PCB [U] PCB [All except U]
S693 C693	5138006000 5054802400	Switch, Reed Capacitor, Mylar $0.01\mu\text{F}$ 100V 10%

10. SEMICONDACTORS LISTS


	Y.					
JRC4558DF (TOP VIEW)	HD74000P (TOP VIEW)	LM13600 (TOP VIEW)	LM324 (TOP VIEW)	M54410P (TOP VIEW)	NE645B (TOP VIEW)	
1 d	1	1 0° 116	1 d°	1 d d d d d d d d d d d d d d d d d d d	1 do p 16 do p n n n n n n n n n n n n n n n n n n	
2SA733P 2SA933LNS	2SC1327T 2SC1684S 2SC1841E	2SA934R	2SC2060Q	2SB750	2SD880Y	
В — С	2SC1844F 2SC945AK 2SD655E C	В — С Е	В	В — Е	B C	
E C B		E C B		B C		
2SC1636-2 2SC1636	2SC2270A-B 2SD985	TA7230P	1S2076 1S2473HJ 0A90R	_	D\$135D → → ←	
B—E	B E				RD4.3EB RD13EB	
	8	100000	EQA01-06R EQA01-06S EQA01-13RF			
E C B		10			SLP-114B	


11. ASSEMBLING HARDWARE CODING LISTS

All screws conform to ISO standards, and have crossrecessed heads, unless otherwise noted.

ISO screws have the head inscribed with a point as in the figure to the right.

FOR EXAMPLE:







^{*}Inner dia. for washers and nuts

	Code	Name	Туре		Code	Name	Type
MACHINE SCREW	R	Round Head Screw		TAPPING SCREW		Binding Head Tapping Screw(A Type)	(g)
	Р	Pan Head Screw			втв	Binding Head Tapping Screw(B Type)	(S)
	T	Stove Head Screw (Truss)	8		RTA	Round Head Tapping Screw(A Type)	
	В	Binding Head Screw	(3)		RTB	Round Head Tapping Screw(B Type)	
	F	Flat Countersunk Head Screw	(X)	SETSCREW	SF	Hex Socket Setscrew(Flat Point)	©
	0	Oval Countersunk Head, Screw			sc	Hex Socket Setscrew(Cup Point)	
WOOD SCREW	RW	Round Head Wood Screw			ss	Slotted Socket Setscrew(Flat Point)	0
TAPTITE SCREW	PTT	Pan Head Taptite Screw	(1)	WASHER	E	E-Ring (Retaining Washer)	3
	WTT	Washer Head Taptite Screw			w	Flat Washer (Plain)	
SEMS SCREW	BSA	Binding Head SEMS Screw(A Type)	3)		sw	Lock Washer (Spring)	
	BSB	Binding Head SEMS Screw(B Type)			LWI	Lock Washer (Internal Teeth)	(222)
	BSF	Binding Head SEMS Screw(F Type)	(B)		LWE	Lock Washer (External Teeth)	ĘŢ
	PSA	Pan Head SEMS Screw(A Type)			TW	Trim Washer (Countersunk)	0
	PSB	Pan Head SEMS Screw(B Type)		NUT	N	Hex Nut	(2)